

IMPORTANT NOTES REGARDING ADAPTED LENSES:

Please note that unless specifically listed, recommendations below are for lenses that use their native mounts only. If you intend to use an adapter to accommodate a non-native lens onto another mount, please contact our staff to confirm the correct lens port combination. Please also note it is not possible to use zoom gears on lenses that require an adapter for mounting to your camera

Above Water Ports: Typically flat ports, above water ports are recommended to make managing water droplets easier due to the smaller surface area of these ports. Whilst still being able to be used underwater, the above water recommendations are best suited for photographic requirements when shooting above the surface of the water.

Over/Under & Underwater Ports: Due to the way light properties work underwater, dome ports are typically recommended for wide angle lenses in order to achieve the best image quality. These ports can also be used above water as well as for capturing Over/Under style image compositions. Dome ports can be paired with extensions to achieve the most desirable distance between the lens element and the dome port element. For lenses longer than 35mm in focal length a flat port (or above water port) is typically recommended.

Select your lens mount option:

[Canon RF](#)

[Sony E](#)

[Zeiss E \(for Sony E Mount\)](#)

[Canon EF](#)

[Nikon Z](#)

[Fujifilm XF](#)

[Fujifilm GF](#)

[Nikon F](#)

[Sigma](#)

[Sigma ART E \(for Sony E Mount\)](#)

[Hasselblad XCD](#)

[Leica L](#)

[Panasonic](#)

[Tokina](#)

[Tamron](#)

[Tamron E Mount](#)

[Rokinon E Mount](#)

[Canon EF-RF Adapted \(RF Body\)](#)

Canon RF Mount Lenses	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
*Please note if you are going to use the Canon Mount Adapter EF-RF, Please contact staff for correct lens ports. The below recommendations apply to EDGE Housings only.				
14-35 f/4 RF	107.8mm	P-80 + P-30ex	PD-100 + P-30ex	Canon RF 14-35 F/4
15-35mm f/2.8 RF	127mm	P-145	PD-100 + P-70ex	Canon RF 15-35 F/2.8
16mm f/2.8 RF	41mm	PD-65	PD-100	N/A
35mm f/1.8 RF	78mm	P-80	PD-100	N/A
50mm f/1.2 L RF	108mm	P-120	N/A	N/A
50mm f/1.8 RF	40mm	P-65	N/A	N/A
85mm f/1.2 L RF	117.3mm	P-130	N/A	N/A
85mm f/2 Macro RF	90.5mm	P-100	N/A	N/A
100mm f/2.8 L Macro RF	148mm	P-160	N/A	N/A
24-70mm f/2.8 RF	144mm	P-145 (no lens filter)	N/A	Canon RF 24-70mm F/2.8
24-105mm f/4 RF	107mm	P-145	N/A	Canon RF 24-105mm F/4
70-200mm f/4 L IS RF	119mm	P-190	N/A	Canon RF 70-200mm F/4
70-200mm f/2.8 L IS RF	205mm	P-215	N/A	Canon RF 70-200mm F/2.8

Canon EF-RF Adapted Lenses	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
*Please note the below recommendations are based off of the Standard EF-RF adapter only				
EF 8-15mm f4 L		PD-65 + P-30Ex	PD-100 + P-30Ex	N/A
EF 16-35mm f2.8 L II		P-65 + P-70Ex	PD-100 + P-70Ex	N/A
EF 16-35mm f2.8 L III		P-120 + P-30Ex	PD-100 + P-70Ex	TBA
EF 24-70mm f2.8 L II		P-145 + P-30Ex (Slight vignette at 24mm)	N/A	TBA
EF 70-200mm f2.8 IS II		P-215 + P-30Ex	N/A	TBA

Sony E Mount	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
14mm f1.8 GM	99.8mm	PD-65 + P-30ex	P-30ex + PD-100	N/A
20mm f1.8 G	84.7mm	P-100	PD-100 + P-30ex	N/A
20mm f1.8 ZA		P-80	PD-100 + P-30ex	N/A
24mm f1.8 ZA	65.5mm	P-80	PD-100	N/A
24mm f1.4 GM	92.4mm	P-100	PD-100 + P-30ex	N/A
28mm f/2	60mm	P-80	PD-100	N/A
24mm f/1.4 GM	94mm	P-100	PD-100 + P-30ex	N/A
35mm f1.4 GM	96mm	P-120	PD-100 + P-30ex	N/A
35mm f/2.8 ZA	36.5mm	P-65	PD-100	N/A

35mm f/1.4 ZA	112mm	P-120	PD-100 + P-70ex	N/A
35mm f/1.8	73mm	P-80	PD-100	N/A
40mm f2.5 G	45mm	P-65	PD-100	N/A
50mm f/1.8	57mm	P-65	N/A	N/A
50mm f/1.2 GM	108mm	P-120	N/A	N/A
50mm f/2.5 G	45mm	P-65	N/A	N/A
55mm f/1.8 ZA	70.5mm	P-80	N/A	N/A
10-18mm f/4	63.5mm	P-65	PD-100	N/A
12-24mm f/4 G	119mm	PD-140	PD-140	Sony 12-24 F/4
12-24mm f/2.8	137mm	P-135	PD-140	Sony 12-24 F/2.8
16-35mm f/2.8 GM	137mm	P-130	PD-140 or PD-100 + P-70ex	Sony 16-35 F/2.8
16-35mm f/4 PZ	89mm	N/A	PD-100 + P-50Ex	N/A
16-35mm f/4 ZA	99mm	P-120	PD-140 or PD-100 + P-70ex	Sony 16-35mm F/4
24-105mm f/4 G	140mm	P-135 + P-30ex (Very slight vignette at 24mm)	N/A	Sony 24-105mm F/4
24-70mm f/2.8 GM	156mm	P-135 + P-30ex	N/A	Sony 24-70mm F/2.8 GM
24-70mm f/2.8 GM II	110mm	P-145	N/A	Sony 24-70mm F/2.8 GM V2
24-70mm f/4 ZA	95mm	P-135	N/A	Sony 24-70mm F/4
28-70mm f/3.5-5.6	97mm	P-100	N/A	N/A
85mm f/1.4 GM	108mm	P-120	N/A	N/A
85mm f/1.8 FE	82mm	P-80	N/A	N/A

90mm f/2.8 Macro G	130.5mm	P-130	N/A	N/A
100mm f/2.8 STF GM	118.1mm	P-130	N/A	N/A
135mm f/1.8 GM	127mm	P-130	N/A	N/A
70-200 f/4 G	175mm	P-190	N/A	Sony 70-200mm F/4 G
70-200mm f/2.8 GM	200mm	P-215	N/A	Sony 70-200mm F/2.8 GM V1
70-200mm f/2.8 GM II	200mm	P-215	N/A	Sony 70-200mm F/2.8 GM V2
28mm f/2 + 16mm Fisheye conversion	117mm	PD-65 + P-50ex	PD-100 + P-50ex	N/A
28mm f/2 + 21mm Wide angle conversion	117mm	PD-65 + P-50ex	PD-100 + P-50ex	N/A

*Please note if you are using adaptors for non Sony E Mount lenses on any of the Sony cameras (ie, Canon EF-Sony E), we advise you to contact staff for correct lens port information based on your choice of adaptor.

Zeiss E Mount Lenses	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
18mm f/2.8 Batis	80mm	TBD	PD-100	N/A
25mm f/2 Batis	78mm	TBD	PD-100	N/A
85mm f/1.8 Batis	92mm	P-100	N/A	N/A

Rokinon E Mount Lenses	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
14mm AF f2.8 FE	80mm	PD-65 + P-30Ex	PD-100 + P-30Ex	N/A

Canon EF Lenses	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
*Please note if you are going to use the Canon Mount Adapter EF-RF, Please contact staff for correct lens ports.				
8-15mm f/4L	83mm	PD-75	PD-100 + P-30EX	N/A
10-22mm f3.5-4.5	90mm	P-100	PD-100 + P-30Ex	N/A
10-18mm f4.5-5.6 IS	72mm	P-80	PD-100	N/A
11-24mm f/4 L	132mm	PD-140	PD-140	Canon 11-24mm F/4 L
14mm f2.8 II L	95mm	P-30ex + PD-65	PD-100 + P-30Ex	N/A
15mm f2.8 Fisheye	63mm	PD-65	PD-100	N/A
16-35mm f2.8	103mm	P-120	PD-140	Canon 16-35mm F/2.8
16-35mm f2.8 II	111.6mm	P-120	PD-140 or PD-100 + P-70 EX	Canon 16-35mm F/2.8 II
16-35mm f2.8 III L	126mm	P-130	PD-140 or PD-100 + P-70 EX	Canon 16-35mm F/2.8 III
16-35mm f4 IS	113mm	P-120	PD-140 or PD-100 + P-70 EX	Canon 16-35mm F/4 IS
17-40mm f4	96.4mm	P-100 (no filter)	PD-100 + P-30Ex	Canon 17-40mm F/4
20mm f2.8	70.6mm	P-80	PD-100	N/A
24mm f1.4 L II USM	87mm	P-100	PD-100 + P-30ex	N/A
24mm f2.8	48.5mm	P-65	PD-100	N/A
24mm f2.8 IS	56mm	P-65	PD-100	N/A
24-70mm f2.8	157mm	P-160	N/A	N/A

24-70mm f2.8 II	144mm	P-145 P-160 for APSC	N/A	Canon 24-70mm F/2.8 II
24-70mm f4 IS	123.5mm	P-135	N/A	N/A
24-105mm f3.5-5.6 STM	104mm	P-145	N/A	N/A
24-105mm f4 IS	140mm	P-145 P-160 for APSC	N/A	Canon 24-105mm F/4 IS
24-105mm f/4 IS II L	160mm	P-135 + P-30 EX for full frame sensor or P-160 for APSC sensor	N/A	Canon 24-105mm F/4 IS II
28mm f1.8	55.6mm	P-65	PD-100	N/A
28mm f2.8 IS	52mm	P-65	PD-100	N/A
35mm f1.4 L	86.2mm	P-100	PD-100 + P-30ex	N/A
35mm f1.4 II L	106mm	P-120	PD-100 + P=30ex	N/A
35mm f2	42.5mm	P-65	PD-100	N/A
35mm f2 IS USM	63mm	P-65	PD-100	N/A
50mm f1.2 L USM	66mm	P-80	N/A	N/A
50mm f1.4	50.5mm	P-65	N/A	N/A
50mm f1.8	41mm	P-65	N/A	N/A
70-200mm f2.8	193.6mm	P-215	N/A	N/A
70-200mm f2.8 IS	197mm	P-215	N/A	Canon 70-200mm F/2.8 IS
70-200mm f2.8 IS II	199mm	P-215	N/A	Canon 70-200mm F/2.8 IS II
70-200mm f/2.8 IS III	199mm	P-215	N/A	Canon 70-200mm F/2.8 IS III
70-200mm f4	172mm	P-190	N/A	N/A

70-200mm f4 IS	172mm	P-190	N/A	N/A
85mm f1.8	71.5mm	P-80	N/A	N/A
85mm f/1.4 L IS	106mm	P-120	N/A	N/A
85mm f1.2 L II USM	97mm	P-100	N/A	N/A
100mm f2	73.5mm	P-80	N/A	N/A
100mm f/2.8 L Macro	123mm	P-130	N/A	N/A
135mm f2	112mm	P-130	N/A	N/A

Nikon Z Mount Lenses	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
20mm f/1.8 S	108.5mm	P-120	PD-100 + P-70ex	N/A
24mm f/1.8 S	96.5mm	P-120	PD-100 + P-30ex	N/A
35mm f/1.8 S	86mm	P-100	PD-100 + P-30ex	N/A
50mm f/1.8 S	86mm	P-100	N/A	N/A
85mm f/1.8 S	99mm	P-120	N/A	N/A
14-24mm f/2.8 S	124.5mm	PD-65 + P-70ex	PD-100 + P-70ex	TBA
14-30mm f/4 S	115mm	PD-100 + P-50ex	PD-100 + P-50ex	Nikon 14-30mm F/4 S
24-70mm f/2.8 S	160mm	P-145	N/A	TBA
70-200 f/2.8 S	220mm	P-190 + P-30ex	N/A	TBA

Fujifilm Lenses	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
14mm f/2.8 R XF	60mm	P-65	PD-100	N/A
16mm f/1.4 R XF	74mm	P-80	PD-100	N/A
18mm f/2 R XF	41mm	P-65	PD-100	N/A
23mm f/1.4 R XF	63mm	P-80	PD-100	N/A
23mm f/2 R XF	52mm	P-65	PD-100	N/A
27mm f/2.8 R XF	25mm	P-65	PD-100	N/A
35mm f/1.4 R XF	56mm	P-65	PD-100	N/A
35mm f/2 R XF	46mm	P-65	PD-100	N/A
50mm f/2 R WR	60mm	P-80	N/A	N/A
56mm f/1.2 R XF	70mm	P-80	N/A	N/A
60mm f/2.4 XF	71mm	P-80	N/A	N/A
90mm f2 R LM WR XF	105mm	P-120	N/A	N/A
8-16mm f/2.8 XF R LM WR	122mm	PD-140	PD-140	TBA
10-24mm f/4 R OIS	87mm	P-80	PD-100	Fuji XF 10-24mm F/4 R OIS
16-55mm f/2.8 R LM WR	76mm	P-135	N/A	Fuji XF 16-55mm F/2.8 R LM WR
18-55mm f/2.8- f/4	76mm	P-100	N/A	N/A
16-80mm f/4 R LM OIS WR		P-135	N/A	Fuji XF 16-80mm F/2.8
50-140mm f/2.8	176mm	P-190	N/A	Fuji XF 50-140mm F/2.8 OIS WR

Fujifilm GF Lenses	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
GF 23mm f4 R LM WR	103.2mm	P-80 + P-30Ex	PD-100 + P-70ex	N/A
GF 30mm f3.5 R WR	100.6mm	P-120	PD-100 + P-70ex	N/A
GF 45mm f4 R R WR	88mm	P-120	PD-100 + P-70ex	N/A
GF 50mm f3.5	49.7mm	P-65	PD-100	N/A
GF 63mm f2.8 R WR	70.3mm	P-80	N/A	N/A
GF 80mm f1.7 R WR	99.8mm	P-120	N/A	N/A
GF 110mm f2 R LM WR	125.8mm	P-130	N/A	N/A
GF 120mm f4 Macro	152.6mm	P-160	N/A	N/A
GF 32-64 f4	116-145mm	P-145	PD-100 + P-70ex	Fuji GF 32-64mm F/4
GF 35-70 f4.5-5.6		P-100	PD-100 + P-30ex	Fuji GF 35-70mm F4.5-5.6
GF 45-100 f4 R LM OIS WR	144.5-173.7	P-145 + P-30ex	N/A	N/A
GF 100-200mm f5.6 R LM OIS WR	183.6mm	P-215	N/A	N/A

Nikon F Mount Lenses	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
*Please note not all Nikon zoom gears will work on the Compac D7200/D7500 Please contact AquaTech directly for the correct zoom gears to work correctly with your D7500, D7200/ D7100 Nikon camera.				
10.5mm f/2.8	62.5mm	PD-50	PD-100	N/A
8-15mm f/3.5-4.5 ED Fisheye	85mm	PD-75	PD-100 + P-30ex	N/A

10-24mm F/3.5-4.5G ED	85mm	P-100	PD-100 + P-30ex	N/A
18-55mm f/3.5-5.6	74mm	P-90	N/A	N/A
14mm f2.8 AF D ED	87mm	PD-65 + P-30ex	PD-100 with P-30Ex	N/A
12-24mm f4	90mm	P-100	PD-100 + P-30ex	N/A
14-24mm f2.8	131.5mm	PD-140	PD-140	Nikon 14-24mm F/2.8
16-35mm f4	128mm	P-130	PD-140 PD-100 + P-70ex	Nikon 16-35mm F/4
16mm f2.8	58mm	PD-50	PD-100	N/A
17-35mm f2.8	106.5mm	P-120	PD-140	Nikon 17-35mm F/2.8
17-55mm f2.8	130mm	P-65 + P-70ex	N/A	N/A
20mm f1.8 G ED	79mm	PD-75	PD-100 + P-30ex	N/A
20mm f2.8	42.5mm	P-65 (DX Format Only)	PD-100	N/A
24mm f1.4 G ED	88.5mm	P-100	PD-100 + P-30ex	N/A
24mm f/1.8 G ED	84mm	P-100	PD-100 + P-30ex	N/A
24mm f2.8	46mm	P-65	PD-100	N/A
24-70mm f2.8	153.5mm	P-160	N/A	Nikon 24-70mm F/2.8
24-70mm f2.8 E ED VR	170mm	P-190	N/A	Nikon 24-70mm F/2.8 E ED VR
28mm f2.8	44.5mm	P-65	N/A	N/A
35mm f1.4 G	89.5mm	P-100	PD-100 + P-30ex	N/A
35mm f1.8 G DX	54mm	P-65	PD-100	N/A
35mm f2	43.5mm	P-65	PD-100	N/A
50mm f1.4	42.5mm	P-65	N/A	N/A
50mm f1.8	39mm	P-65	N/A	N/A

58mm f/1.4 G	70mm	P-80	N/A	N/A
85mm f1.4G	84mm	P-100	N/A	N/A
85mm f1.8G	74mm	P-100	N/A	N/A
105mm f1.4E ED	107mm	P-120	N/A	N/A
70-200mm f2.8 VR	215.5mm	P-215	N/A	N/A
70-200mm f2.8 VR II	205.5mm	P-215	N/A	Nikon 70-200mm F/2.8 II
70-200mm f/2.8 E FL VR	208mm	P-215	N/A	Nikon 70-200mm F/2.8 E FL VR
70-200mm f4 VR	179mm	P-190	N/A	NZ 70-200mm F/4 VR
300mm f4 E PF ED VR	147mm	P-160	N/A	N/A

Sigma Lenses	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
8mm f/3.5 circular fisheye	68.6mm	PD-65	PD-100	N/A
10-20mm f/3.5	79.5mm	P-100	PD-100	N/A
14mm f/1.8 ART	126mm	PD-140	PD-140	N/A
15mm f/2.8 EX DG fisheye	85mm	PD-100	PD-100	N/A
12-24mm f/4 ART	132mm	PD-140	PD-140	Sigma 12-24mm F/4 ART
12-24mm f/4.5-5.6	102mm	PD-100 + P-30ex	PD-100 + P-30Ex	N/A
14-24mm f/2.8 ART	135mm	PD-140	PD-140	TBA

18-35mm f/1.8 ART	121mm	P-130	PD-140	Sigma 18-35mm F/1.8 ART
20mm f/1.4 ART	130mm	N/A	PD-140	N/A
24mm f1.4 DG ART	91mm	P-100	PD-100 + P-30ex	N/A
24-35mm f/2 ART	122mm	P-100 + P-30ex	PD-100 + P-70ex	N/A
24-70mm f/2.8 EF	107mm	P-145 (Slight vignette at 24mm)	N/A	N/A
30mm f1.4 DC ART	59mm	P-65	PD-100	N/A
35mm f1.4 DG ART	94mm	P-100	PD-100 + P-30ex	N/A
35mm 1.4 Sony E Mount	119mm	P-130	PD-100 + P-70ex	N/A
35mm f/2 DG DN	67.4mm	P-80	PD-100	N/A
50mm f/1.4 DG ART	100mm	P-120	N/A	N/A
50mm f/1.4 EX DG HSM	69mm	P-80	N/A	N/A
85mm f/1.4 DG HSM ART	128mm	P-130	N/A	N/A
85mm f/1.4 EX DG HSM	86mm	P-100	N/A	N/A
Sigma ART Lens for Sony E Mount	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
24mmf/1.4 DG HSM ART	116mm	P-130	PD-100 + P-70ex	N/A
24-70 f/2.8 DG ART	124.9mm	P-135 + P-30ex	N/A	Sigma 24-70 f 2.8 E
35mmf/1.4 DG HSM ART	120mm	P-130	PD-100 + P-70ex	N/A
50mm f/1.4 DG HSM ART	126mm	P-130	N/A	N/A
85mmf/1.4 DG HSM ART	153mm	P-160	N/A	N/A

Tamron Lenses	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
15-30mm f/2.8 Di VC	145mm	PD-75 + P-70ex	PD-100 + P-70ex	N/A
28-75mm f/2.8 Di III		P-145	N/A	TBA
70-200mm F/2.8 Di VC USD G2	194mm	P-215	N/A	N/A
70-210mm F/4 Di VC USD	177mm	P-190	N/A	N/A

Tamron E Mount Lenses	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
17-28mm f2.8 f/2.8 Di III RXD	99mm	P-100	PD-100 + P-30Ex	N/A
28-75mm f2.8 Di III RXD Lens	118mm	P-145	N/A	TBA
28-75mm f2.8 Di III VXD G2	117mm	P-145	N/A	TBA

Hasselblad XCD Lenses	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
21mm f/4	106mm	P-80	PD-100 + P-30ex	N/A
30mm f/3.5	88mm	P-65	P-65 or PD-100	N/A
45mm f/3.5	75mm	P-65	PD-100	N/A
45mm P f/4	52mm	P-65	PD-100	N/A

65mm f/2.8	91mm	P-65	N/A	N/A
80mm f/1.9	112mm	P-100	N/A	N/A
90mm f/3.2	100mm	P-80	N/A	N/A
120mm f/3.5	150mm	P-130	N/A	N/A
135mm f/2.8	149mm	P-130	N/A	N/A
135mm + converter f/4.8	196mm	P-190	N/A	N/A
35-75mm f/3.5-4.5	145mm	P-130	N/A	N/A

Leica Lenses	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
28mm f/2	102mm	P-100	PD-100 + P-30ex	N/A
35mm f/2	102mm	P-100	PD-100 + P-30ex	N/A
75mm f/2	102mm	P-100	N/A	N/A
90mm f/2	102mm	P-100	N/A	N/A
16-35mm f/3.5-4.5	130mm	P-65 + P-50Ex	PD-140	Leica SL 16-35mm F/3.5-4
24-70mm f/2.8		P-145	N/A	Leica SL 24-70mm F/2.8
24-90mm f/2.8-4		P-100 + P-70ex (best for 50mm-90mm)	PD-140 (best for 24mm-35mm)	Leica SL 24-90mm F/2.8-4
90-280mm f/2.8-4		P-215 + P-30Ex	N/A	Leica SL 90-280mm F/2.8-4

Panasonic Lenses	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
7-14mm f/4	83mm	PD-75	PD-100	PZ 7-14mm f/4
12-35mm f/2.8	74mm	P-100	N/A	PZ 12-35mm f/2.8
12-60mm f/2.8	92mm	P-135	N/A	TBA
8-18mm f2.8-f/4	88mm	P-100	PD-100 + P-30ex	TBA
35-100mm f/2.8	100mm	P-100	N/A	PZ 35-100mm f/2.8

Tokina Lenses	Lens Length	Above Water	Over/Under & Underwater	Zoom Gear
10-17mm f/3.5-4.5	71.7mm	PD-75	PD-100	N/A
11-16mm f/2.8	89mm	P-100	PD-100 + P-30ex	TZ 11-16mm f/2.8
11-20mm f/2.8	92mm	P-100	PD-100 + P-30ex	N/A

Port Selection Information

PD-50:	This is a low profile dome port designed for the Nikon Fisheye Lenses and primarily used above water.
PD-65:	This is a dome port designed for the Fisheye lens and primarily used above water.
PD-100:	This is a large dome port with an element machined from a 9" Diameter dome. This is primarily used for underwater and over/under shots. The port has an outer diameter of 8".

<p>PD-140:</p>	<p>This is a large dome port with an element machined from a 9" Diameter dome. This is primarily used for underwater and over/under shots for lenses with longer physical lengths and wider diameters such as a 11-24mm zoom lens. The port has an outer diameter of 8".</p>
<p>Flat Element Ports: eg; P-65, P-160 etc</p>	<p>All other ports are equipped with flat elements. For best results the lens element should be as close as possible to the port element. These ports are used mainly for above water shooting.</p>
<p>Extension Ports: P-30Ex, P-50Ex and P-70Ex:</p>	<p>These are extension rings that increase the length of the port by 30mm or 70mm. The ring screws onto the housing and the port screws into the ring.</p>