

GETTING STARTED

Please fully charge device before long-term use. See "Charging the Device".

Heat Mode

Press & hold button for 2-seconds to turn on/off heat mode.

Indicator displays 1/2/3 for "Low/Med/High" Heat setting.

Double tap button to cycle through temperature setpoints:

"1" (Low) - "2" (Medium) - "3" (High)

Device will now be in HEAT mode until powered off by holding button again for 2-seconds or battery depletes.

Power Bank Mode

Simply plug any USB charge cord into battery and connect to your device.

Automatically enters Power Bank Mode and displays remaining battery capacity. Tapping button 1x at anytime will display battery status.

Mobile devices may be charged by connecting any USB charge cord to the Full USB port. Works with any iPhone or Android phones and many other accessories using their own provided USB charge cables (not included).

NOTE: This function will automatically turn off Heat Mode as both heating and charging cannot be done at the same time to protect the battery.

CHARGING THE DEVICE

The supplied cable or any other standard charge cable may be used to charge the device by plugging the smaller Type-C USB end into the device and the larger USB end into any standard USB charging port such as a USB wall adapter, computer USB port, car charger, and more. Battery status indicator will flash 0-100% while charging. Battery typically requires about 4-hours to fully charge.

Charge cable may be unplugged when it reaches 100%.

*Lithium batteries should always be kept fully charged as often as possible.

Fully recharge at least every 3-6 months when storing for long durations.

SPECIFICATIONS

Battery Capacity: 10,000mAh / 37Wh

Input: USB-C 5V/3.0A DC

Output: USB 5V/3.0A DC

Charging duration: About 4 Hours

Heating durations: 8-12 Hours



Warnings:

Do not expose to high temperatures or fire

Keep away from water and other liquids

Surface clean only – do not immerse

Use by children should be under a responsible adult's supervision

When storing BoneView HotPocket between uses, ensure the battery is charged. The battery should be charged at least once every 3 months during longer-term storage.

SUPPORT INFORMATION

Please email BoneView directly: Support@BoneView.com

Or call 339-OPG-INFO

Take advantage of BoneView's generous warranty support and register your product today -

Visit: www.Boneview.com/Warranty

We PROUDLY honor BoneView's 100% Customer Satisfaction Guarantee, so **please contact us directly** for assistance, returns, exchanges, refunds, or anything else. Let us make our products and service exceed your expectations!

WARRANTY

Limited One Year Warranty

This product is warranted to be free from defects in materials and workmanship for a period of one (1) year from date of original purchase. If the Unit should become defective within the warranty period, we will repair any defective parts free of charge. The warranty does not cover external parts, unauthorized repairs, or unusual wear and/or damage resulting from accident, natural disasters, or use of the unit for other than intended use. This warranty gives you specific legal rights and you may also have other rights, which may vary from state to state in the USA. This device has NO customer serviceable parts. Opening, dismantling or tampering with this unit in any manner will void the warranty. This unit must be returned to the original manufacturer for all service and repairs. Please contact the manufacturer directly to obtain Return Authorization before shipping the unit to the manufacturer.

Please register at www.boneview.com/warranty to instantly extend warranty to 2-years.

SUPPORT CONTACT

NEED HELP?

Please visit us at: www.BoneView.com

Contact Support at: Support@BoneView.com

(339)OPG-INFO



Don't return product to original purchase location. Contact us directly for returns, replacement, or support: Support@BoneView.com

We are always looking to hear product feedback, reviews, and see photos from fellow outdoors enthusiasts testing our products in the field.

Amazon customers, please share your honest product feedback by visiting:

www.amazon.com/review/create-review



Good luck this season and please share your photos and success stories with us online using **#BoneView** on Instagram or Facebook.

DISCLAIMER: Outdoor Performance Gear, LLC d/b/a BoneView shall not be liable for any damage, loss, or injury from the use or misuse of this product.

manual print size front and back:

90-mm (wide) x 195-mm (tall)

Folded size is 90mm (wide) x 65mm (tall)
when folded to thirds