



HotPocket Hand Warmer + Phone Charger + LED Flashlight

Getting Started – 3 Functions

1) Hand Warmer Function

- a. Hold down the power/mode button for 3-5 seconds. The red indicator light will blink slowly indicating the **Low Temperature Mode**
- b. Push the power/mode button once to change to **High Temperature Mode**. The red indicator will blink quickly.
- c. Turn off your BoneView HotPocket by holding down the power/mode button for 3-5 seconds.

2) Flashlight Function

- a. Press the power/mode button 2 times. Turn off by pressing the power/mode button 2 times again.
- b. Turn on Strobe/SOS Light by pushing the power/mode button 3 times. Repeat to turn off.

3) Phone/Device Charging Function

- a. Simply connect your phone's USB charging cord to the port labeled "OUT DC5V/1.5A". Works with iPhone, Android and many other devices (phone charging cables not included).

Charging the BoneView HotPocket

A charging cable is supplied with your BoneView HotPocket. To charge, simply connect the smaller microUSB end to your BoneView HotPocket at the port labeled "IN DC5V". Connect the larger end of the cable to any USB charging port such as laptop, desktop, plug-in adapter or car adapter (not supplied).

The 3 blue power level indicator lights will begin to blink. As the battery charges, the lights will become continuously lit instead of blinking. The device is fully charged once all the blue lights are on and not blinking. It is important to fully charge the device before using it; the initial charge will take approximately 4 hours.

Warnings:

Do not expose to high temperatures or fire

Keep away from water and other liquids

Surface clean only – do not immerse

Use by children should be under a responsible adult's supervision

When storing BoneView HotPocket between uses, ensure the battery is charged. The battery should be charged at least once every 3 months.