



Bluetooth Boombox Buddy System

Owner's Guide

Model SP-SK86gTW

INTRODUCTION

Thank you for your purchase of the SHARKK Bluetooth Boombox Buddy System. Please take the time to read this manual carefully before you begin using your new items.

The Boombox Buddy System is more than just two arbitrarily linked speakers. Rather it is a true wireless, surround sound experience with a transportive result that is truly greater than the mere sum of its parts. Featuring two Bluetooth 4.0 powered wireless boomboxes, the Boombox Buddy System is packed with advanced features and equipped with the very latest in wireless technology. And with each speaker equipped with a high-capacity 4400mAh battery, you can rock out for up to 18 hours on a single charge!

INTRODUCTION


In addition to the Boombox Buddy System, the SHARKK Lifestyle Brand is pleased to be able to offer a wide variety of consumer accessories across many different product categories. Keyboards, wallets, speakers and mobile power banks are but a few of the items that make up our extensive online catalog and we welcome you to visit us and browse our handpicked selection of the latest consumer accessories at sharkk.com.

Here at SHARKK, the quality of our products and the satisfaction of our customers are the two greatest passions of our enterprise, as we endeavor to bring you top quality items at competitive prices.

WHAT'S WHAT

Box Content

- 2x Bluetooth Boombox Speakers
- 2x USB Charging Cables
- 2x 3.5mm Audio Cables
- 1x Dual Port Power Adapter
- 1x User Manual



WHAT'S WHAT

Power Indicator ①

- Flashing Blue: device is turned on and active.
- Solid Red: device is charging (will turn off when fully charged).
- Solid Green: device is in AUX mode.
- Flashing Blue and Red: indicates active Bluetooth pairing.

Power Button ②

- Press and hold to turn device on/off. You will hear an audible indication when powering on and the power indicator will turn blue. The light around this button will turn green while speaker is in AUX mode.
- While the speakers are paired together, turning either off will turn both off.

Headphone Jack ③

- Insert headphones here, they will be automatically detected by the speaker.

AUX input ④

- This port is for connecting your speaker to external media devices.

Micro USB Port ⑤

- This port is for charging only and cannot be used for external media devices.

Prev/Next ⑥

- Use this button to navigate between tracks when Bluetooth device is connected.

Pairing Button ⑦

- Use this button to pair your Buddy-System speakers together.

Note: Always pair speaker "A" with your media-device before pairing the speakers together.

WHAT'S WHAT

Thermal Sensor ⑧

- Detects the heat of a human hand and will automatically activate the devices frosted LED button-backlighting.

Play/Pause ⑨

- While in Bluetooth mode, press and hold to initiate Bluetooth pairing, then continue to use normally for playing and pausing.

Phone Button ⑩

- When connected via Bluetooth, press and hold to activate Siri or S-Voice.
- Incoming Call: press once to answer/end, press and hold to decline call.
- Only speaker “A” (the main speaker) has access to phone-related functionality.

V-/V+ ⑪

- Adjusts volume. While in Bluetooth mode, a beeping sound will alert you when you have reached maximum volume.

NFC Area ⑫

- Hold your device over this area to use NFC for Bluetooth connection.

Microphone ⑬

- For best results, keep within 3 feet of the Mic while speaking.

INSTRUCTIONS

To Charge the Speakers

Insert the power cable into the Micro-USB port of the device. Charging begins automatically even if the device is powered off.

Bluetooth

1. Power on speaker “A” and hold your phone or other device within 3 feet of the speaker, press and hold the **Play/Pause** button for 3 seconds, the system will then enter pairing mode and the indicator light should be flashing blue and red.
2. Pairing mode will automatically be canceled (signaled by a beep) after 3 minutes. To re-enter pairing mode, simply begin again at step #1.
3. Ensure Bluetooth is enabled on the device you wish to pair with the speaker

INSTRUCTIONS

4. The speaker will appear as “SHARKK” when scanning for available devices.
5. When selecting “SHARKK” from the list, if prompted for a Password (sometimes called a “Passkey”, “PIN Number”), enter “0000”.
6. The speaker will record this device as the last device paired.
7. Once you have speaker “A” successfully paired with your device, follow these instructions to pair the two speakers together.
 - Power on speaker “B” and position it next to (i.e. within 3 feet of) speaker “A”.
 - Press the “A=>B” button on speaker “A” and then press the “A=>B” button on speaker “B”. The power indicator on both speakers should begin flashing blue and red alternately as they attempt to pair (this may take up to 10 seconds).

INSTRUCTIONS

- A tone will sound when the speakers have successfully paired.
- Speaker “A” should always be paired to the music player before it is connected to speaker “B”.
- It is important that speaker “A” always be paired first as alternating between the two could lead to unintended results.
- If pairing fails it is necessary to clear pairing history on both speakers.
- Press for 3 seconds on both the **Prev** and **Next** buttons together to clear pairing history.
- This procedure must be done on both speakers to fully clear pairing history. When done successfully, a red light will flash.

INSTRUCTIONS

8. When in Bluetooth mode you can switch to “AUX” by inserting the AUX cord into the speaker AUX input. While in AUX mode, the green circular light around the power button will remain on. .
9. Incoming calls will override music and other media with an incoming call voice alert, simply press the Phone button to answer/end or press and hold to decline the call. Press the Phone button to answer a second incoming call.
10. Press and hold the Phone button for three seconds to activate Siri/S-Voice on speaker “A”.
11. Should you wish to switch music players, simply press and hold the **Play/Pause** button of Speaker A to enter pairing mode. Pair the device like normal.

INSTRUCTIONS

Video Tutorials

For more help and for walk-through video tutorials please go to our website at www.sharkk.com/boombox-buddy and click on the videos.

Range

Be sure to keep Speaker A within 26 feet (8 meters) of both Speaker B and the connected media device at all times for optimal buddy-system performance.

If the two speakers get separated from each other while they are paired, (i.e. being moved too far away from each other,) the speakers will attempt to re-pair with each other for two minutes. If the auto re-pair mode fails to reconnect and it may be necessary to restart both speakers in order for them to connect to each other again.

AUX

- Insert the AUX cord into the designated port to automatically switch the speaker to AUX mode. While in AUX mode, the green circular light around the power button will remain on.
- Connect your music player to the AUX input with the supplied 3.5mm audio cable. Insert one end into the headphone port on the music player, and insert the other end into the AUX input.
- Inserting a cable into the headphone port of speaker “A” will disable the speakers (as the headphone connection is now active).

Note: *Speakers cannot pair with each other via Bluetooth while in AUX mode.*

INSTRUCTIONS

NFC

Turn on the NFC function of the device you wish to connect to your speaker. Touch the device to the speakers NFC area located on the top of the speaker next to the Mic port and power indicator. The speaker will connect automatically.

Troubleshooting:

If speaker B has poor sound quality:

1. Make sure the speakers are within the appropriate range (26 feet).
2. Make sure there are no other bluetooth devices nearby, causing interference.
3. Make sure there are no obstacles between them.
4. Clear pairing history on devices by pressing the **Prev** and **Next** buttons together until the red light flashes once.
5. Next re-pair your speakers.
6. Speaker B should now maintain a constant flow of music.

APPENDIX

Features

1. Bluetooth Version 4.0.
2. Increased Bluetooth transmission rate and higher audio fidelity with greater power efficiency.
3. Supports: NFC, Siri and S-Voice.
4. Battery status shows on iPhone / iPod / iPad.
5. Dual 10W loudspeakers produce high quality stereo sound.
6. Buddy pairing system allows for true wireless stereo left-right sound.

7. Advanced Lithium Battery allows for up to 18 hours playing time!
8. Thermal heat sensor automatically activates frosted LED backlighting for the button on the speaker.
9. Built-in phone functions allows you to answer or decline incoming calls.

APPENDIX

Specifications

1. Operation Voltage: 3.7 V
2. Charging Voltage: 5V
3. Output Power: 5Watts * 2 per unit
4. Speaker Specs: 52mm 2 Ohms 5W
5. Frequency Response: 60Hz ~ 20Khz
6. Lithium Battery Capacity: 4400mAh per unit
7. THD \leq 0.5%
8. SNR \geq 90dB
9. Dimensions: 60mm * 70mm * 190mm

Proper Use

1. Please charge your new speakers for at least two hours before first use.
2. To prevent damage and risk of electrical shock, do not expose this device to dust, vibration, rain, water or liquids of any kind.
3. Do not place device in close proximity to open flames or extreme heat sources. Always place your device on level, flat and stable surfaces.
4. Avoid placing items on top of the speakers.
5. Do not use excessive force when pressing buttons or handling speakers.
6. To clean your speakers, use a dry, soft cloth or minimally damp cloth without any corrosive solvent or cleaning agent.

APPENDIX

Safety

To prevent fire, shock or injury, please do not disassemble or replace any parts of these speakers. In the event that your device becomes damaged or in need of repair, please contact a professional maintenance or qualified service center for assistance. We are not responsible for any personal injury or property damage caused by improper use of this product.

Please do not allow the use of these speakers by small children without proper adult supervision.

Warranty

Your new SHARKK Boombox Buddy System is covered by a Limited Manufacturer's Warranty. Details of the warranty are as follows: for a period of one (1)

year from the date of retail purchase, SHARKK warrants that this product is free of any defects in manufacturing, materials and workmanship.

During the warranty period, we shall, at our sole discretion, repair or replace any defective parts within a reasonable period of time and free of charge.

FCC Compliant

These devices comply with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) These devices may not cause harmful interference, and (2) These devices must accept any interference received, including interference that may cause undesired operation.

APPENDIX

Support

As with all SHARKK products, the Boombox Buddy System comes with our quality assurance and satisfaction guarantee. If you should experience any technical or performance issues with your device, or if you simply have a question or inquiry, we invite you to contact our customer service department at support@sharkk.com, and we will do everything in our power to help resolve the issue.

KEEP IN TOUCH

Please take a moment to check us out on Facebook, Twitter and Instagram where you can post pictures, share your experience and join the ever-growing SHARKK online community.

By joining the SHARKK Facebook page you will be eligible for special promotions and giveaways, as well as being among the first to know about new products, discounts and sales.



@ShopSHARKK



SHARKK



@SHARKKLifestyle



Support@Sharkk.com
All rights reserved
© Sharkk