


LOGIIX™ TEMPO

User manual


1



2



3



### Package Contents



### Features & Specs

- Flat tip design rests comfortably in your ear, without directly plugging your ear
- Built-in microphone and controls
- Flat and ultra flexible cable
- 90° angle plug

### Controls

#### 1 Music Controls

- Play / pause
- Next song
- Previous song
- Volume up
- Volume down

- press the ►|| button
- double press the ►|| button
- triple press the ►|| button
- press the + button
- press the - button

#### 2 Call Controls

- Answer / end call
- Decline call

- press the ►|| button
- long press the ►|| button

### General Warnings for Use & Care

- 1 Do not disassemble product in an attempt to make repairs.
- 2 Do not use near or around water.
- 3 Do not store in a high temperature environment (such as a car).
- 4 Do not use in high humidity places.
- 5 To extend the life of your **LOGIIX TEMPO**, keep it free from dust. Simply wipe it down with a clean, dry cloth. Do not use any abrasive cleaners.
- 6 When not in use, store earphones in a cool, dry area, out of direct sunlight.

### Troubleshooting

- 1 Audio is cutting out or absent: unplug auxiliary cable & make sure there is no dust before reconnecting
- 2 Audio is only coming out of one earbud or sound is distorted: make sure auxiliary plug is plugged completely
- 3 If all else fails, contact: [customerservice@logiix.net](mailto:customerservice@logiix.net)

### Warranty

**LOGIIX TEMPO** is covered under a one year limited warranty for product defects. This warranty does not cover products which have been:

- damaged by consumer;
- opened and/or altered in any way;
- subject to normal wear and tear.

If you are experiencing any issues with your product that you can not resolve using this user manual, please contact us.

To ensure the best support from our customer service team, please email us a picture of your proof of purchase, along with a photo of the defect to: [customerservice@logiix.net](mailto:customerservice@logiix.net).

LOGIIX™ TEMPO

Manuel utilisateur


1



2



3



## Contenu du Colis



## Caractéristiques

La conception à bout plat repose confortablement dans votre oreille, sans boucher votre oreille

Microphone et contrôles intégrés

Câble plat et ultra flexible

Fiche auxiliaire à 90°

## Contrôles

### 1 Contrôles de Musique

Jouer / pause

appuyez sur le bouton ►||

Prochaine chanson

appuyez deux fois sur le bouton ►||

chanson précédente

appuyez trois fois sur le bouton ►||

Monter le son

appuyez sur le bouton +

Baisser le volume

appuyez sur le bouton -

### 2 Contrôles d'appel

Répondre /

mettre fin à l'appel

appuyez sur le bouton ►||

Efuser l'appel

appuyez longuement sur le bouton ►||

## Avertissements généraux

1 Ne démontez pas le produit dans une tentative de faire des réparations.

2 Ne pas utiliser près ou autour de l'eau.

3 Ne pas garder dans un environnement à haute température

4 Ne pas utiliser dans des endroits très humides.

5 Pour prolonger la vie de votre **LOGIIX TEMPO**, le garder exempt de poussière. Essuyer avec un chiffon propre et sec. Ne pas utiliser de nettoyants abrasifs.

6 Lorsqu'il n'est pas utilisé, rangez le haut-parleur dans un endroit frais et sec, à l'abri de la lumière directe du soleil.

## Dépannage

1 Audio coupe ou absent: débranchez le câble auxiliaire et assurez-vous qu'il n'y a pas de poussière avant de rebrancher

2 Audio ne fonctionne que dans un écouteur ou le son est déformé: assurez-vous que la prise auxiliaire est branché complètement

3 Si cela ne fonctionne pas, contacter : [customerservice@logiix.net](mailto:customerservice@logiix.net)

## Garantie

**LOGIIX TEMPO** par LOGIIX est couvert par une garantie limitée pour les défauts du produit. Cette garantie ne couvre pas les produits qui ont été:

- endommagé par le consommateur;
- ouvert et ou modifié de quelque façon;
- en raison de l'usure normale.

Si vous rencontrez des problèmes avec votre produit que vous ne pouvez pas résoudre en utilisant ce mode d'emploi, s'il vous plaît contactez-nous.

Pour assurer la meilleure assistance de notre équipe de service à la clientèle, s'il vous plaît envoyez-nous une photo de votre preuve d'achat, avec une photo de la pièce défectueuse à: [customerservice@logiix.net](mailto:customerservice@logiix.net).