



Bakeware Liner

LINE YOUR BAKEWARE FOR NON-STICK BAKING

100% non-stick Bakeware Liner

No need to oil or butter pan
= low fat, low calorie baking.

Cut to size to fit your pan.

Reusable for years.

Easy Clean-up.

Dishwasher safe.



Dimensions 13 x 15 3/4"
Can be cut to size.



Re-usable for years.



Dishwasher safe.
One wipe clean.

Also perfect for use as
a non-stick liner in the
microwave or
toaster oven.



Item#:
C4033PP

UPC Code:
5412460011017