



Oven Crisper Sheet & Grill Mat

PERFECT HEAT CIRCULATION
ENSURES CRISP FOOD EVERY TIME!




The Non-Stick Mat allows steam to escape, avoiding soggy food and prevents sticking.

USE ON THE GRILL TO PREVENT FOOD FROM FALLING THROUGH THE GRATES!



Size 14.5" x 14.5"
Reusable on both sides.



Non-stick so there is no need to add oil or butter.



Dishwasher, freezer and oven safe up to 500°F.

Ideal for Heating Up:

- PIZZA
- OVEN FRIES
- CHICKEN WINGS
- CHICKEN NUGGETS
- SPRING ROLLS
- PIES
- PASTRY
- FISH STICKS
- BREAD ROLLS
- BAGUETTE
- TURNOVER
- ANYTHING WITH PUFFY PASTRY



Item #: TC1414X1

UPC Code 890906000309