



ToasterBags (Set of 2)

PREPARE A GRILLED SANDWICH
IN YOUR TOASTER!



The ToasterBag with its non-stick surface cooks snacks in just a couple of minutes. Grill sandwiches, pizza slices, pita bread, panini, garlic bread and so much more! Can also be used in your countertop grill or toaster oven to keep them clean.

REUSABLE UP TO 50 TIMES!



Place Sandwich
in bag.



Toast as usual.




Serve!



Crumb-free toasting reduces cross-contact:
perfect for gluten-free breads!

One-wipe clean and dishwasher safe!



Item #:
C1814X2

UPC code:
892647000051