




# CS900 Cell Phone

## Quick Start User Guide

# Your Cell Phone



- 1. SOS Button** *(Automatically calls the SOS numbers)*
- 2. LED Light** *(Will flash on a incoming call, a missed call, an unread message and when charging your phone)*
- 3. Quick Hang Up Calls**

- 4. Quick Answer Calls**
- 5. Loudspeaker**
- 6. Headset, Jack 3.5mm**
- 7. Torch key** *(Press and hold for flashlight)*
- 8. Micro USB charger port**
- 9. Volume keys + / -**

# Your Cell Phone

**10.** Left Menu / Main Menu

**11.** Call Answer / Call Log

**12.** Block Robocallers

*(Press Block Now)*

**13.** \* Key *(Press and hold this button to enter the following symbols: \* / + )*

**14.** Receiver

**15.** Navigation keys *(Up / Down / Right / Left)*

**16.** Right menu key *(On the idle screen this button takes you to the Phonebook menu)*

**17.** Hang Up Calls  
Power On/Off

**18.** Speed dial 2

**19.** Speed dial 1

**20.** # Key *(Press and hold to switch between silent mode and general modes)*



# Insert SIM Card

Fig. 1





Fig. 2




1. Make sure the phone is switched off and the charger is disconnected.
2. Turn the phone over (back of phone facing you), push and slide down the back cover (see Fig. 1).
3. If the battery is in place, remove it.
4. Insert the SIM Card (see Fig. 2).

**Note:** The CS900 is an "Unlocked Phone" and uses a Standard SIM Card.

# Getting Started

Make sure a SIM card is inserted in your CS900 and the battery is charged.

1. Press and hold  to switch the phone on.
2. If prompted, choose your language and press OK.  
If you have not inserted a SIM card, the CS900 will display '**Insert SIM**'. No SIM card, only emergency call available.

## Phone Book

Can hold 1000 numbers within the phone and 250 numbers on the SIM.

## Speed Dial

Press once for Picture Phone

Press right on the navigation button

Press the Call Button



**Note:** Charge the battery for at least 12 hours before using the phone for the first time.

# Call Blocking Menu

The CS900 is pre-loaded with CPR's nuisance robocall lists so from the start you will see a reduction of Robocalls.

The quickest way to block calls is by using the big red **BLOCK NOW** button on the telephone keypad. This will disconnect the call and add the caller to the Black List.

## Call Blocking Menu

1. Press the **BLOCK NOW** button.
2. Scroll to Black List to set up blocking specific numbers from calling you, here you can add/remove up to 900 numbers.
3. To turn the Black List function OFF, scroll to Black List and then scroll to Turn ON/OFF (the black list function is on by default).

## Block Unavailable/Private Calls

Turn on the Whitelist: Only the Numbers Pre-Programmed can call.

# SOS Emergency Assist Settings

When the SOS button on the rear of the phone is pressed the CS900 will send an SMS text message saying "Emergency, need help" followed by a phone call to all preset emergency numbers.

## Setup SOS Emergency numbers

1. Add up to 5 emergency numbers by simply pressing left on the navigation button.



Please note you must add at least 1 telephone number for Emergency Assist to function.

To make an Emergency Assist Call, press the SOS button on the back of the mobile phone for 3 seconds.

To cancel the Emergency Assist Call, simply press the SOS button again.



If you have any questions or require assistance  
please contact our friendly customer service team.

Email: [support@cprcallblocker.com](mailto:support@cprcallblocker.com)

UK Customer Care  
0800 652 7780

US Customer Care  
818 - 927 - 0871

AUS Customer Care  
1 800 187 358

Lakeside Technology Park  
Swansea | SA7 9FF

2711 Centerville Road  
Delaware | 19808-1645

Level 20 Tower A  
Sydney | 2067

**CS900 is NOT compatible with any CDMA Networks  
such as Verizon or Sprint**