



How to Use Your Fire Pit

Step 1

Remove the nested flame ring and set it aside.

Step 2

Start by placing your tinder, kindling and small wood pieces in the center of the fire pit.

FOR BEST RESULTS, DO NOT OVERFILL WITH WOOD THAT COVERS OR EXTENDS ABOVE THE TOP AIR HOLES.

Step 3

Light your fire.

Step 4

Place the flame ring back on top of the fire pit with the angled edges pointing upward.

THIS WILL PROVIDE PROTECTION FROM THE WIND AND ENHANCE THE LOOK OF THE FLAMES.

CORRECT



INCORRECT



Step 5

As your ember bed gets hotter, start adding in 1-3 pieces of wood. As those catch, add enough wood to fill the burn chamber.

Step 6

When you're ready to call it a night, let the fire pit burn out on its own.

Step 7

After the fire pit has completely cooled, turn it over to empty the ash.

Storage and Care

Caring for your fire pit correctly will prolong its look and usability.

After each use, wait until the unit has completely cooled down then turn the fire pit over to empty any remaining ash. If you want to wipe it down, use only a dry cloth.

Always place your fire pit in its carrying case or under its weatherproof cover (certain models) when not in use.

Due to extremely high temperatures, discoloration of the fire pit will occur and is considered normal. Stainless steel has an increased resistance to rust; however, it is not rust-proof.

Prolonged exposure to moisture may result in increased staining and/or rusting. Due to extremely high temperatures inside, the fire pit may show signs of staining/rust. This is normal and will not affect normal use.

Tips & Good Things to Know

Use dry hard woods for best results.

When you first use your fire pit, the unique double-wall airflow within the unit will take approximately 5–15 minutes to achieve full efficiency. The more evenly your fire burns inside your fire pit, the more prominent the flame pattern showing the secondary combustion will appear.

Overfilling your fire pit above the top air holes will decrease efficiency and will produce more smoke.

Prolonged exposure to harsh weather will increase rust and discoloration.

User Warnings

1. Solo Stove fire pits are for outdoor use only and should not be used in a building, a garage, or any other enclosed area.
2. Solo Stove fire pits are extremely hot when in use. Never attempt to touch or move your fire pit during use or before it has completely cooled down.
3. Do not use Solo Stove fire pits for indoor heating. Toxic carbon monoxide can accumulate and cause asphyxiation and possibly death.
4. Solo Stove fire pits are not for commercial use.
5. Solo Stove fire pits are not to be operated by children. Solo Stove fire pits are not toys.
6. Never leave Solo Stove fire pits unattended, especially when children and pets are nearby.
7. Solo Stove fire pits are not to be used in a boat or recreational vehicle.
8. Always use Solo Stove fire pits in accordance with all applicable local, state, and national codes. Contact your local fire department for details.
9. When using Solo Stove fire pits, exercise the same precautions you would with any open fire.
10. The use of alcohol, prescription or non-prescription drugs may impair the consumer's ability to operate Solo Stove fire pits safely.
11. Do not use Solo Stove fire pits until you have read the operating instructions and user warnings.
12. Solo Stove fire pits are designed for use with standard firewood logs and may not function properly with other fuel sources.
13. Do not alter or modify Solo Stove fire pits in any manner.
14. Do not store or use gasoline or any other flammable vapors or liquids in the vicinity of Solo Stove fire pits.
15. Do not store or use LP gas cylinders within 30 feet of Solo Stove fire pits while in operation.
16. Do not use Solo Stove fire pits near automobiles, trucks, vans, or recreational vehicles.
17. Do not use Solo Stove fire pits in any explosive environment. Keep the area around Solo Stove fire pits clear and free of any combustible materials, gasoline, or any other flammable liquids.
18. Do not use Solo Stove fire pits under any overhead or near any unprotected combustible constructions. Avoid using under or near any overhanging trees or shrubs.
19. Always use Solo Stove fire pits on a level non-combustible surface. Use on wood or composite decks at your own risk.
20. Do not wear flammable or loose clothing when operating Solo Stove fire pits.
21. Do not use Solo Stove fire pits in windy conditions.
22. Do not use gasoline, kerosene, diesel fuel, lighter fluid, alcohol or any other flammable liquid to light or relight Solo Stove fire pits.
23. Keep all electrical cords away from Solo Stove fire pits.
24. All surfaces of Solo Stove fire pits are extremely hot when in operation. To avoid burns and serious injury, do not touch your Solo Stove fire pit until the fire is completely out and it has completely cooled. Never touch the coals or ash to see if they're still warm.
25. Do not attempt to move or store your Solo Stove fire pit until all fire, coals, and ashes are completely extinguished and the unit has completely cooled.
26. Do not remove any coals or ash or clean your Solo Stove fire pit until the coals and ash are completely extinguished and the unit has completely cooled.
27. Do not lean over Solo Stove fire pits when lighting or when they are in use.
28. Avoid breathing smoke from the fire and avoid getting smoke in your eyes.
29. Solo Stove fire pits should be inspected and cleaned regularly after each use.
30. After a period of non-use, check your Solo Stove fire pit for signs of damage and creosote buildup. Do not operate until necessary repairs and/or cleanup is done.
31. Do not use water to extinguish the fire as this could cause damage to the fire pit as well as injury to the user.
32. Serious injury, death, and/or property damage may occur if the above instructions are not followed exactly.