



Please have your bicycle professionally assembled or have your assembly verified by a professional bicycle mechanic. Please review the enclosed Bicycle Owner's Manual in full before attempting assembly or riding the bicycle.

Home assembly will be much easier if you watch our assembly video first. Visit www.prioritybicycles.com and click on "Instructions"

Your bicycle may require a simple hub adjustment. If you do not perform this one time adjustment you will periodically feel your gears disengage or shift between gears 1 and 2 automatically. To remedy this issue, please follow these simple steps:

Step 1. - Shift into gear 2

Step 2. - Loosen the nut on the rear hub control unit barrel adjuster with 10mm wrench or adjustable wrench (figure A)

Step 3. - Turn the nut counter-clockwise until the yellow line sits just past the line closest to the hub (figure B)

Step 4. - Re-tighten the nut

Questions? Contact us anytime:

- Info@prioritybicycles.com
- (917) 819-1665



Figure A

