


Just Right 2Person Workstation

www.jasonl.com.au

Need help! Call us on **1300 527 665**



The first step is to assemble the desks individually. The following steps contain in detail the parts and processes to follow, for each of them.



Just Right 2Person Workstation


www.jasonl.com.au


Need help! Call us on 1300 527 665





Accessory list


Attention: The drawings below are only for reference which might be slightly different from the actual object, please in kind prevail. Any tools missing or installation problems, please contact the customer service firstly.











Just Right 2Person Workstation


www.jasonl.com.au

Need help! Call us on

1300 527 665



 ● "▲" Adjust the de ● "▼" Adjust the de 	esk upwards esk downwards	
Instruction Press the UP button or DOWN button of desk surface.	to lift or lower the height	UP button
		Attention
e fault you met is not listed below, pl	and eliminate the common fault and error. lease contact with your supplier. Only the vable for investigating and correcting	 Power supply: AC100V-240V,50/60HZ Service Environment: 0-40°C Unplug the power plug before cleaning, wipe the dust on surface with slight wet dishcloth when cleaning, be careful not to let the drops into the internal parts, not loose the connector. The electric box contains electronic components, metals, plastics, wires etc., so dispose of it in accordance with each country's environmental legislation, not the general household waste. Check carefully to ensure correct and complete assembly before using. Be familiar with all functions and program settings of the product before first use. Children are forbidden to play on the product because of unforeseen action when playing,
following tips will help you detected e fault you met is not listed below, pl nufacturer and professionals are cap se fault and error.	lease contact with your supplier. Only the able for investigating and correcting	 Power supply: AC100V-240V,50/60HZ Service Environment: 0-40°C Unplug the power plug before cleaning, wipe the dust on surface with slight wet dishdoth when cleaning, be careful not to let the drops into the internal parts, not loose the connector. The electric box contains electronic components, metals, plastics, wires etc., so dispose of it in accordance with each country's environmental legislation, not the general household waste. Check carefully to ensure correct and complete assembly before using. Be familiar with all functions and program settings of the product before first use. Children are forbidden to play on the product because of unforeseen action when playing, so any dangerous consequences caused by this improper action will not be on Slight noise caused by the V-ribbed belto or brake system due to structure will not have any effect on the use of the equipment.
following tips will help you detected e fault you met is not listed below, pl ufacturer and professionals are cap e fault and error. Fault phenomenon	lease contact with your supplier. Only the	 Power supply: AC100V-240V,50/60HZ Service Environment: 0-40°C Unplug the power plug before cleaning, wipe the dust on surface with slight wet dishdoth when cleaning, be careful not to let the drops into the internal parts, not loose the connector. The electric box contains electronic components, metals, plastics, wires etc., so dispose of it in accordance with each country's environmental legislation, not the general household waste. Check carefully to ensure correct and complete assembly before using. Be familiar with all functions and program settings of the product before first use. Children are forbidden to play on the product because of unforeseen action when playing, so any dangerous consequences caused by this improper action will not be on Slight noise caused by the V-ribbed belt or brake system due to structure will not have any effect on the use of the equipment. Ocrosive or abrasive materials are forbidden to clean the equipment. Must ensure that the cleaner used will not play the the environment. Please make sure there is no hazard sources in your operating environment, e.g., do not
following tips will help you detected e fault you met is not listed below, pl ufacturer and professionals are cap e fault and error. Fault phenomenon	lease contact with your supplier. Only the able for investigating and correcting Method 1.Check if all the cables be	 Power supply: AC100V-240V, 50/60HZ Service Environment: 0-40°C Unplug the power plug before cleaning, wipe the dust on surface with slight wet dishdoth when cleaning, be careful not to let the drops into the internal parts, not loose the connector. The electric box contains electronic components, metals, plastics, wires etc., so dispose of it in accordance with each country's environmental legislation, not the general household waste. Check carefully to ensure correct and complete assembly before using. Be familiar with all functions and program settings of the product before first use. Children are forbidden to play on the product because of unforeseen action when playing, so any dangerous consequences caused by this improper action will not be on Slight noise caused by the V-ribbed belt or brake system due to structure will not have any effect on the use of the equipment. Corrosive or abrasive materials are forbidden to clean the equipment. Must ensure that the cleaner used will not pollute the environment. Please make sure there is no hazard sources in your operating environment, e.g., do not litter the tools around. Always be careful to treat the packaging materials in order to avoid any possible danger, e.g. plastic bag may lead to choking hazard to children.
following tips will help you detected e fault you met is not listed below, pl ufacturer and professionals are cap e fault and error. Fault phenomenon lo response while long pressing own arrow after connected with power supply	lease contact with your supplier. Only the able for investigating and correcting Method 1.Check if all the cables be connected well	 Power supply: AC100V-240V,50/60HZ Service Environment: 0-40°C Unplug the power plug before cleaning, wipe the dust on surface with slight wet dishdoth when cleaning, be careful not to let the drops into the internal parts, not loose the connector. The electric box contains electronic components, metals, plastics, wires etc., so dispose of it in accordance with each country's environmental legislation, not the general household waste. Check carefully to ensure correct and complete assembly before using. Be familiar with all functions and program settings of the product before first use. Children are forbidden to play on the product because of unforeseen action when playing, so any dangerous consequences caused by this improper action will not be on Slight noise caused by the V-ribbed belt or brake system due to structure will not have any effect on the use of the equipment. Pease make sure there is no hazard sources in your operating environment. e.g., do not litter the tools around. Always be careful to treat the packaging materials in order to avoid any possible danger, e.g. plastic bag may lead to choking hazard to children. Keep the original package of the equipment if necessary in case of the future use in transportation.
following tips will help you detected e fault you met is not listed below, pl iufacturer and professionals are cap ie fault and error. Fault phenomenon Vo response while long pressing lown arrow after connected with a power supply	lease contact with your supplier. Only the able for investigating and correcting Method 1.Check if all the cables be connected well 2.Contact your supplier or dealer	 Power supply: AC100V-240V,50/60HZ Service Environment: 0-40°C Unplug the power plug before cleaning, wipe the dust on surface with slight wet dishdoth when cleaning, be careful not to let the drops into the internal parts, not loose the connector. The electric box contains electronic components, metals, plastics, wires etc., so dispose of it in accordance with each country's environmental legislation, not the general household waste. Check carefully to ensure correct and complete assembly before using. Be familiar with all functions and program settings of the product before first use. Children are forbidden to play on the product because of unforeseen action when playing, so any dangerous consequences caused by this improper action will not be on Slight noise caused by the V-ribbed belt or brake system due to structure will not have any effect on the use of the equipment. Orrosive or abrasive materials are forbidden to clean the equipment. Must ensure that the cleaner used will not pollute the environment. Please make sure there is no hazard sources in your operating environment. e.g., do not litter the tools around. Always be careful to treat the packaging materials in order to avoid any possible danger, e.g. plastic bag may lead to choking hazard to children. Keep the original package of the equipment if necessary in case of the future use in transportation. The following tips will help you detected and eliminate the common fault and error. If the
following tips will help you detected e fault you met is not listed below, pl iufacturer and professionals are cap te fault and error.	lease contact with your supplier. Only the able for investigating and correcting Method 1.Check if all the cables be connected well 2.Contact your supplier or dealer 1.Check if overloaded, max loading: 70kg;	 Power supply: AC100V-240V,50/60HZ Service Environment: 0-40°C Unplug the power plug before cleaning, wipe the dust on surface with slight wet dishdoth when cleaning, be careful not to let the drops into the internal parts, not loose the connector. The electric box contains electronic components, metals, plastics, wires etc., so dispose of it in accordance with each country's environmental legislation, not the general household waste. Check carefully to ensure correct and complete assembly before using. Be familiar with all functions and program settings of the product before first use. Children are forbidden to play on the product because of unforeseen action when playing, so any dangerous consequences caused by this improper action will not be on Slight noise caused by the V-ribbed belt or brake system due to structure will not have any effect on the use of the equipment. Pease make sure there is no hazard sources in your operating environment. e.g., do not litter the tools around. Always be careful to treat the packaging materials in order to avoid any possible danger, e.g. plastic bag may lead to choking hazard to children. Keep the original package of the equipment if necessary in case of the future use in transportation.





health from uncontrolled waste disposal, recycle it responsibly to promote

the sustainable reuse of material resources. To return your used device,

ē

recycling.





Take off the end cap using allen key 3mm.

Slide in post adjustable L bracket from the side groove, and put the top end caps back to its place using 3mm allen key.


Just Right 2Person Workstation

www.jasonl.com.au

Need help! Call us on

1300 527 665





Please secure the L Bracket underneath the desk by drilling the 2 screws into the underneath Top (screws are provided). **Note**: Please do not drill the screws into the screen post.