
www.jasonl.com.au

Need help!





Just Right 4 Person Workstation


www.jasonl.com.au

Need help!

Call us on **1300 527 665**



The first step is to assemble the desks individually. The following steps contain in detail the parts and processes to follow, for each of them.



www.jasonl.com.au

Need help!


Call us on **1300 527 665**



Accessory list

Attention: The drawings below are only for reference which might be slightly different from the actual object, please in kind prevail. Any tools missing or installation problems, please contact the customer service firstly.
















Part list


No.	Part	Qty	No.	Part	Qty	No.	Part	Qty
1	Pedestal	2	2	Column	1	3	Column	1
4	Supporting beam	1	5	Transmission rod	1	6	Supporting plate	2
7	Adapter	1	8	Baffle	2	9	Power cable	1




www.jasonl.com.au

Need help!









Just Right 4 Person Workstation

www.jasonl.com.au

Need help!








www.jasonl.com.au


Just Right 4 Person Workstation


Need help!














Just Right 4 Person Workstation

www.jasonl.com.au

Need help!

Call us on **1300 527 665**



How to use handswitch

•	"▲"	Adjust the desk upwards
•	"▼"	Adjust the desk downwards


Instruction

Press the UP button or DOWN button to lift or lower the height of desk surface.

Common fault treatment

The following tips will help you detected and eliminate the common fault and error. If the fault you met is not listed below, please contact with your supplier. Only the manufacturer and professionals are capable for investigating and correcting those fault and error.

Fault phenomenon	Method			
No response while long pressing down arrow after connected with	1.Check if all the cables be connected well			
a power supply	2.Contact your supplier or dealer			
The deal-ten sould not be lifted	1.Check if overloaded, max loading: 70kg;			
The desktop could not be lifted	2.Contact your supplier or dealer			
Overwork (Duty cycle:Max 2min on/30min OFF)	1.Restart it after suspend for 30mins for the working time is too long			
(Buty Gyolc.Wax 211111 017 0011111 017)	2.Contact your supplier or dealer			





- 1. Power supply: AC100V-240V,50/60HZ
- 2. Service Environment: 0-40°C
- 3. Unplug the power plug before cleaning, wipe the dust on surface with slight wet dishcloth when cleaning, be careful not to let the drops into the internal parts, not loose the connector.
- 4. The electric box contains electronic components, metals, plastics, wires etc., so dispose of it in accordance with each country's environmental legislation, not the general household waste.
- 5. Check carefully to ensure correct and complete assembly before using.
- 6. Be familiar with all functions and program settings of the product before first use.
- 7. Children are forbidden to play on the product because of unforeseen action when playing, so any dangerous consequences caused by this improper action will not be on
- 8. Slight noise caused by the V-ribbed belt or brake system due to structure will not have any effect on the use of the equipment.
- Corrosive or abrasive materials are forbidden to clean the equipment. Must ensure that the cleaner used will not pollute the environment.
- 10. Please make sure there is no hazard sources in your operating environment. e.g., do not litter the tools around. Always be careful to treat the packaging materials in order to avoid any possible danger, e.g. plastic bag may lead to choking hazard to children.
- 11. Keep the original package of the equipment if necessary in case of the future use in transportation
- 12. The following tips will help you detected and eliminate the common fault and error. If the fault you met is not listed below, please contact with your supplier. Only the manufacturer and professionals are capable for investigating and correcting those fault and error.

Waste disposal






This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Just Right 4 Person Workstation

www.jasonl.com.au

Need help!







www.jasonl.com.au

Need help!







Take off the end cap using allen key 3mm.


Slide in post adjustable L bracket from the side groove, and put the top end caps back to its place using 3mm allen key.

www.jasonl.com.au

Need help!

Call us on **1300 527 665**





Please secure the L Bracket underneath the desks by drilling the 2 screws into the underneath Top (screws are provided).

Note: Please do not drill the screws into the screen post.