# ASSEMBLY INSTRUCTIONS Litewall Workstation 4 Person

www.jasonl.com.au


Need help!

Call us on **1300 527 665** 





Size: 1200mm



**Tools Required:** Power screwdriver; Allen key set.



2 persons required for installation

#### **ASSEMBLY INSTRUCTIONS Litewall Workstation** 4 Person

Size: 1200mm

**COMPONENTS** 

5 Feets x6

**SCREWS** 

Legs x2 (1625mm) 2 Beams x8 (800mm) 3 Connector Frame x1


> M6x40mm Hex Head x32 M6x35mm Hex Head x4

www.jasonl.com.au

**Need help!** 

Call us on 1300 527 665





## ASSEMBLY INSTRUCTIONS Litewall Workstation 4 Person


www.jasonl.com.au

**Need help!** 


Call us on **1300 527 665** 




Size: 1200mm




Screw the feet to each leg and T leg.



Attach 4x 800mm beams to 1625mm leg using M8x25mm dome head screw. Attach connector frame from diagram 2 to 4 beams using M8x25mm dome head screws.



Assemble connector frames. Attach the 2 T legs to the double connector frame using M6x35mm hex scews x4.



Attach the remaining 4x 800mm beams to the connector frame using M8x25mm dome head screw.

## Litewall Workstation 4 Person

Size: 1200mm

#### www.jasonl.com.au

Need help! Call us on

1300 527 665



