Do not use the battery if contacts become exposed to solid or liquid matter.

Shorts can result in fire or an explosion of a battery.
Do not touch tips when hot. Severe burns can result in.
Do not touch hot material. Severe burns can result in.
If the device gets too hot in use, please stop using it for a while.

Not for use with nicotine or other nicotine salt products.

Not an ENDS device.

Disclaimers:

People under 21 years of age are not permitted to purchase or use this device. Non-smokers, children, and women breastfeeding should not use this product. The device is not a medical device and is not intended to diagnose, cure or prevent any diseases or other conditions. The manufacturers and sellers will not be responsible for any consequential or incidental damage resulting from the sale or use of any merchandise.



Original and Exclusive Manufacturer: Shenzhen Yocan Technology Co.,Ltd www.yocan.com

Sha'er Industrial Area, Shajing Street, Baoan District, Shenzhen, China.





Safety Warning & Instructions

Please read information carefully before using the product and keep it in a safe place:


Safety Warning

- 1. Do not expose the device to extreme temperatures.
- 2. Do not charge your battery through a car.
- 3. Do not over charge or charge unattended.
- 4. Do not use the device while charging.
- 5. Do not disassemble the device or change the battery. For any post-sale support or assistance, kindly reach out to your direct seller.

https://www.yocan.com/after-sale-support

Specification: Size: 157.3x14.1mm Battery Capacity: 400mAh Charging Type: 5V/0.45A Type-C Charging Time: 1.0hour Resistance Range: >0.8Ω Package Content: 1x Blade (Tip K2 pre-installed) 1x Extra Tip (K1) 1x Tip Cover 1x Type-C USB Cable 1x Instructions Manual

How To Use



- 1. Turn on/off: Click the power button 5 times within 2 seconds. Blue light flashes 5 times.
- 2. Install the tip: Remove the tip cover, attach the ceramic tip to the connection base at your desired angle. Blue light will stay on for 1 second to indicate a successful connection.
- 3. Adjustable Voltage: 3.0V ightarrow 3.6V ightarrow 4.2V

 $\mathsf{Blue} \to \mathsf{Green} \to \mathsf{Red}$

To change voltage setting, click the power button 3 times within 2 seconds.

- 4. Press and hold the button to start working, 15s auto cut-off (Blue light flashes 5 times).
- *Caution: the tip gets very hot. Be careful when handling. Turn off the device when finished and use the cap for storage.
- 5. Charging: 400mAh built-in battery, use the included type-c cable. While charging, the red light remains on, and it turns off when fully charged.

DO NOT LEAVE YOUR DEVICE CONNECTED TO YOUR CHARGER FOR EXTENDED PERIODS OF TIME. ONCE CHARGING IS COMPLETED, THE BATTERY WILL BEGIN TO DRAIN OVER TIME. DO NOT LEAVE CHARGERS PLUGGED IN AND UNATTENDED IN A HOT AREA OR NEAR FLAMABLE OBJECTS AS THIS COULD BE A FIRE HAZARD.

Protection:

Safety Cut-off: If the device is heating continuously for more than 15 seconds, the blue light will flash 5 times quickly and stop working.

No atomizer: Blue light flashes 3 times.

Short-circuit: Red light flashes 5 times.

Low battery: Red light flashes 10 times and stops working.

Caution:

Keep the device away from any environment involving strong acids, alkaline, combustible materials, water, or any other liquids.

Do not keep in hot cars or store above the room temperature of 74F.

Do not use damaged batteries. If the battery casing is damaged, discontinue use and safely recycle the battery.