



## INSTALLATION OF ALL B20, B16, B16R, S16H, SXLH MAILBOXES

CONTENTS OF THIS PACKAGE INCLUDE:  
*(1) MAILBOX, (2) KEYS, (4) BOLTS, (4) WASHERS, (4) NUTS*

### PLACEMENT:

*Customers are required to contact the local post office before installing the mailbox to ensure proper placement at your location. General placement:*

Height: 41 to 45 inches from road surface to point of mail entry

Setback: 6 to 8 inches from front face of curb or road edge to face of mailbox

### ATTACHMENT TO POST:

1. Align holes in bottom of mailbox with holes in post top plate.
2. Insert bolts through mailbox (bolt head in mailbox, threads down.)
3. Place washer then nut on threads and tighten until snug.
4. Remove excess bolt length for higher security.

### LOCK MAINTENANCE:

Annual lubrication is recommended. If damaged, replacements are available through STEELTECH MAILBOXES or most locksmiths. The lock is a NATIONAL #C8735.

*Note: Mail carriers do not carry keys to open individual mailboxes. Therefore, the outgoing mail cannot be secured in a locked compartment while awaiting pickup.*

