

SR-016

SR-016

Model Code List

Brand	Model Code	Brand	Model Code
AIRWELL	0529, 0555-0556	LIANGYU	0233, 0451, 1257, 3523
AUCMA	0288-0296, 0462, 2337, 3534	LITTLE DUCK	0527, 0532, 1556, 2070
AUX	0297-0300, 0451, 0474, 0475, 2860, 3370	LOREN-SEBO	0255, 0471, 0472, 1496, 3543
BANSHEN	0264, 1288, 3848	MACQUAY	0234-0237, 0465, 2283, 3820
BOERKA	0383, 0434, 0436, 0437, 3967	MICOM	0415, 1439, 2463
CARRIER	0203-0209, 0456-0458, 0482-0486, 0563-0565	MIDEA	0260-0265, 0526, 1284, 2310
CHANGHONG	0301-0308, 1325, 2353, 3982	mitsubishi	0001-0045, 0476-0479, 0522, 0523, 0568, 0582, 3628
CHIGO	0379-0382, 0489, 0515, 1916, 2940	NORITZ	0431, 1455, 2468
CHOFU	0184-0187, 1721, 3771	PANASONIC	0138-0154, 0483, 0490-0492, 2019, 3738
CHUNLAN	0345-0350, 0450, 0453, 3932	National	0138-0154, 0483, 0490-0492, 2019, 3738
CORONA	0155-0163, 0459, 2206	PANDA	0378, 0890, 1405
CONROWA	0377, 1913, 3961	PHILCO	0210, 0211, 0487, 0488, 3795
DAEWOO	0203-0209, 0406, 2256, 3990	PROTON	0421-0423, 2507, 3593
DAIKIN	0171-0183, 0566, 0577, 2220, 3758	RAYBO	0362-0367, 1387, 2925
DOCTOR	0221, 0449, 2497, 3850	ROWA	0369, 0438, 0439, 0494, 0527, 0531, 1975, 3510
DONGBAO	0355-0361, 2403, 3430	Sabro	0435, 0506-0508, 2483, 3579
DONGXINBAO	0413, 2461, 3997	SAIJO DENKI	0212-0215, 1238, 3285
Electrolux	0216-0220, 0569, 1753, 3802	SAMPO	0424-0426, 1448, 3497
FEDDERS	0498, 0499, 0528	SAMSUNG	0188-0196, 0516, 0518, 2239, 3772
FRESTECH	0277, 0519, 0520, 1813, 3349	SANYO	0046-0095, 0559, 0529, 0530, 1090, 3678
FUJIN	0001-0009, 0273-0281, 0786	SASUKI	0254, 0470, 2006, 3838
FUJITSU	0127-0137, 0464, 0552-0554, 1158, 3720	SHANGLING	0384-0388, 0444, 0445, 3969
FUNAI	0430, 0481, 1966, 3502	SHARP	0096-0106, 0525, 1633, 2150, 2656
GALANZ	0371, 0372, 0521, 1395, 2933, 3956	SHINCO	0351-0354, 0454-0456, 2912
General	0639, 1152, 2180, 3711	SHUANGLU	0376, 0404-0407, 0480, 3476
GLEE	0398, 0399, 2446, 3983	SHUAIKANG	0288, 0800, 1311
GOLDSTAR	0201, 0466-0469, 2515	SONGGE	0428, 0429, 1965, 2988
GREE	0309-0316, 0482, 0512, 0513	SOVA	0409, 0410, 2457, 3482
HAIER	0266-0272, 0453-0455, 3852	SUMMER	0427, 1963, 2485, 3499
HISENSE	0332-0335, 0517, 1869, 2895, 3917	SUNDURG	0257, 0505, 1793, 3841
HITACHI	0118-0126, 1148, 2679, 3709	SWAN	0434, 0477, 0516, 0524, 0946, 1556
HUABAO	0336-0344, 1879, 3409, 3926	TADIRAN	0246-0251, 2295, 3833
HUAKE	0408, 1432, 2765, 3992	TATUNG	0419, 0420, 1955, 2979
HUAMEI	0402, 0460-0465, 1997, 3533	TCL	0273-0281, 0476, 0493, 0570, 1299, 3347
HUALING	0317-0325, 0452, 2500, 3906	TECO	0256, 0473-0475, 1280
HUIKANG	0368, 0441-0443, 2416, 3514	TIANDI	0415, 0927, 1538, 3999
HYUNDAI	0202, 0433, 0480, 1226, 2250	TOSHIBA	0107-0117, 0479, 0561, 0562, 1647, 3181
JDC	0373, 0440, 1397, 3000	TRANE	0227-0232, 0739, 2276
JINDA	0414, 1950, 2536	UNI-AIR	0222-0224, 0450, 3522
JINSONG	0389-0391, 0446-0448, 3462	WEILI	0393-0396, 2442, 3979
JOHSON	0245, 0492, 2028, 3829	Whirlpool	0164-0170, 0502, 2038, 3752
KANGLI	0374, 0375, 2935, 3958	WINIA	0481, 0550, 1505, 3553
KELON	0282-0287, 0473, 0485-0488	XILENG	0411, 0412, 2460, 3995
KELVINATOR	0151, 0197, 0203	XINLE	0400, 0401, 2960, 3985
KLIMATAIR	0225, 0226, 0452, 1988, 3810	YANGZI(YAIR)	0403, 1427, 3475
KOLIN	0416-0418, 1952, 2465, 3539	YINYAN	0258, 0259, 0326-0331, 0478, 2888
KONKA	0397, 0457-0459, 2507, 3981	YORK	0107, 0238-0243, 0573, 2287, 3312
LG	0197-0200, 0514, 2050, 3730	Zhen bao	0639, 1164, 2176, 3200

UNIVERSAL A/C REMOTE

- Controls over 10,000 models of air conditioner worldwide
- Smart one key operating with full AUTO function
- One button easy operating "G. COOL" & "G. HEAT"
- Autotimer On/OFF with memory
- Room thermometer



MADE IN CHINA

SR-016

Multi Function Air Conditioner Remote User Guide

Product Description

SR-016 universal remote is designed to suit more than 10,000 models of air conditioner worldwide. With user friendly programs, it can be quickly set up and easy for use. The smart "AUTO" key gives you one key solution to turn on your air conditioner without selecting running mode, temperature, fan settings. Which means SR-016 will automatically chose right operation mode for you in all seasons. Also "G. COOL" and "G. HEAT" function keys let you rapid to gain the right settings to turn on the A/C with consideration of saving energy. The AUTOTIMER ON/OFF function makes your life much enjoyable when using the air conditioner. Using above intelligent functions correctly will reduce the power consumption to save your power bills. Please read this User Guide carefully before use the remote.

Model Code Set Up

1. Insert 2 xAAA (UM-4, R03) batteries in the battery compartment. The LCD clock appears, and you are ready to set up the remote.
2. Find the brand code from "Model Code List".
3. Press SELECT key, the code on the LCD blinks. Enter 4-digit code you selected in. Code is confirmed.

Note: Try each code from the same brand one by one, until your remote can operate the air conditioner.

Auto Search Code setting

If you do not know the brand of air conditioner or you cannot find required brand from "Model Code List", please do the following steps:

1. Aim the remote control toward air conditioner, then press "SELECT" key for 5 seconds, brand code on LCD will flash and brand code is added automatically. The remote will emit signal accordingly. Once the indoor unit receives correct signal, you will hear a "beep". The air conditioner will be turned on. Then press any key to confirm immediately.
2. After turning on the air conditioner, try other function keys. If they do not work, repeat above steps until it is correct.

Clock Set Up

1. Press "clock" key, the clock on LCD will flash.
2. Press "TIME+" or "TIME-" key to adjust time.
3. Press "clock" key again or wait 5 seconds until the clock on LCD stops flashing. The time is set.

Using G. COOL and G. HEAT

Press "G. Cool" or "G Heat" key, air conditioner will be rapidly set in cooling or heating mode and turn on with right temperature (programming with consideration of both comfortable and energy saving)

Note: Temperature also can be adjusted by pressing TEMP "▲" or "▼" keys during "G. COOL" and "G. HEAT" mode.

AUTO key function

Press "AUTO" key, your air conditioner will be turn on with programmed smart mode. Which will automatically set up cooling or heating mode in summer and winter according room temperature, set fan speed in "middle" and swing in "auto".
Note: Temperature can also be adjusted by pressing TEMP "▲" or "▼" keys accordingly.

Set Up Autotimer ON/OFF

Timer on: (Can only be set up for using when the air conditioner is off.)

1. Press the "TIMER ON" key, the LCD displays the clock symbol ⌚ and time will be flashing.
2. Press "TIME+" or "TIME-" key to adjust start time for air conditioner automatically ON.
3. The time will stop flashing after 5 seconds. The LCD displays current time and clock symbol ⌚. AUTO TIMER ON setting is complete.

Timer off: (Can only be set up for using when the air conditioner is on.)

1. Press the "TIMER OFF" key, the LCD displays the clock symbol ⌚ and time will be flashing.
2. Press "TIME+" or "TIME-" key to adjust the off time for air conditioner automatically OFF.
3. The time will stop flashing after 5 seconds. The LCD displays current time and clock symbol ⌚. AUTO TIMER OFF setting is complete.

Notes

1. When remote in TIMER ON/OFF operation, ⌚ symbol appears and remote must aim toward air conditioner unit.
2. The remote has memory to keep your last AUTO TIMER ON/OFF settings. That means you can turn ON or OFF the air conditioner every day automatically on the same setting time without change settings.
3. To deactivate timer: You need press TIMER ON or OFF key twice accordingly.

Display Room Temperature

Press "ROOM TEMP" key, LCD displays current room temperature as a thermometer.

Attention

1. If the remote has not been used for a long time, remove the batteries to avoid leakage. When the LCD looks dim, please change batteries.(New and old batteries should not be used together) After the batteries are replaced every time, it is not necessary to set brand code again.
2. The manufacturer reserves the right to change the parameters and functions of the product.

Technical Parameters

Controllable distance : Large than 8 meters

Power supply voltage: DC 3 V

Battery model: Battery AAA(UM-4, R03)×2

Dimension: L127mm×W48mm×D22mm

Weight: Appro 66.5g (excluding batteries)