


JBW

www.JBW.com

RONDA 1069

DISPLAY AND BUTTONS



SETTING THE TIME

1. Pull the crown out to the 1st position.
 2. Turn the crown clockwise to set hour, minute to the desired time.
- *Note:** For watches with 24 hours display you might need to advance 12 hours to synchronize the AM/PM cycle.
3. Push the crown back to the normal position.

ATTENTION: For watches with a screwdown crown, unscrew to set time and when finished screw back crown fully to avoid water entering the module. Crown covers should only be rotated 90 degrees clock-wise to access the crown.

CAUTION

1. Do not touch internal components other than the batteries.
2. Keep your watch in a cool dry place.
3. Avoid abrasions as scratching may eventually affect the case and bracelet.

BATTERY INSTRUCTIONS

1. Mixed usage of a different type of battery or use of new and used battery is not recommended.
2. Battery should be inserted with correct polarity.
3. Supply terminals should not be short-circuited.