


# JBW

www.JBW.com

MIYOTA 2115

## DISPLAY AND BUTTONS



## SETTING THE TIME

1. Pull the crown out to the 2nd position.
2. Turn the crown to set desired hour and minute hands.
3. Push the crown back to the normal position.

## SETTING THE DATE

1. Pull the crown out to the 1st position.
2. Turn the crown counter clockwise to set the date.  
\*Note: Do not adjust date between 9:00 PM and 1:00 AM. Date may not change correctly the following day.
3. Push the crown back to the normal position.

## CAUTION

1. Do not touch internal components other than the batteries.
2. Keep your watch in a cool dry place.
3. Avoid abrasions as scratching may eventually affect the case and bracelet.

## BATTERY INSTRUCTIONS

1. Mixed usage of a different type of battery or use of new and used battery is not recommended.
2. Battery should be inserted with correct polarity.
3. Supply terminals should not be short-circuited.