

**BACK BAY**  
WATCH COMPANY

Owned and operated by proud Bostonians, Back Bay Watch Company is a collection of Boston centric men's and women's watches that capitalize on the classic look and feel of the city.

Named after the iconic streets of Boston, the watches are perfect for those who share their passion for Beantown.


Thank you for purchasing a Back Bay Watch. Back Bays are made with solid 316 stainless steel cases, high quality Quartz movements and are water resistant to 5ATM. To ensure proper use, please read these instructions carefully.

Avoid exposing your watch to violent shocks and extreme temperatures. Do not expose your watch to any chemicals. Your Back Bay watch is water resistant to 5ATM, however to ensure longevity models with genuine leather straps should not be submerged.

**Before using:** In order to start the watch, please remove the plastic stopper then push the crown against the watch.

# Chronograph Watch

**Setting time:** Pull crown B to the 3rd position. Turn the crown to set hour and minute hands. When the crown B is pushed back to the 1st position, the small second hand begins to run on the lower dial.




**Setting the date:** Pull the crown out to the 2nd position. Turn the crown counter-clockwise to set the date. After the date has been set, push the crown back to position 1.

\*If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change on the following day.

## Using Chronograph

The chronograph's stopwatch can be started and stopped each time button "A" is pressed.

Pressing Button C resets the stopwatch, both the seconds hand and 60 minute hand will return to the zero position.



## Chronograph Reset

This procedure should be performed after replacing the battery or when the chronograph second hand does not return to the zero position after the chronograph has been reset.

Pull the crown out to the 2nd position. Press button "A" to set the chronograph second hand to the zero position. The chronograph hand can be advanced rapidly by continuously pressing button "A" Once the hand have been zeroed, return the crown to the normal position.

\* Do not push the crown to its normal position while the chronograph second hand is returning to the zero position. Pushing the crown to it's normal position stops the second hand causing it to register it's current position as the "zero position" regardless of it's location.

## **Warranty**

Back Bay Watches has a limited warranty that covers manufacturer defects for 12 months after your original purchase date. The warranty does not cover normal wear and tear such as batteries, strap damage, accidental damage to the glass, water damage or theft. Proof of purchase is required for all warranty claims and service requests.

**Battery Change:** We highly recommend that you take your watch to a jeweler to replace the batteries.

**Questions or issues?**

[info@backbaywatches.com](mailto:info@backbaywatches.com)





Copyright © 2018 Back Bay Watch Co.  
All rights reserved.