



1

Attach your Bixpy adapter to your Bixpy Jet

1. Align connector pins
2. Pull nose latch forward to allow metal toe to sit flush
3. Attach power cord (turn 180° and “click” closed)
4. Close rear spring latch



2

Attach your Bixpy Jet to your paddle board

1. Remove existing fin
2. Slide motor into finbox - motor outlet points to rear of board
3. Use provided fin key to lock your motor into place



3

Connect your battery

1. Run your power cable to your battery output connector
2. Attached power cord (turn 180° and “click” closed)
3. Secure battery onto your paddle board using bungee cords or Velcro (not provided in this kit)
4. If you need, extension cords are available at: www.bixpy.com



4

Turn on your system and have fun

1. Use your magnetic kill switch to turn on your system
2. Use your Bixpy remote to run your motor (forward/reverse/stop)
3. Use your paddle to steer your board
4. Have fun on the water and be safe!



Motorizing your personal craft may require you to register your craft. Please check your local rules and regulations. Further information at: www.bixpy.com. Always wear a life jacket when on water and carry your paddle with you at all times. NEVER motor further than you can paddle back under your own power. Always consider that malfunctions with your equipment can happen and ensure you can get back safely in case of such malfunctions. You MUST read your motor and battery user manual prior to using Bixpy products and agree to all the conditions. Respect others and wildlife at all times - on and off water.