

How To Make a Rosette

1. Make a prong-backed button using standard button assembly procedures.
2. Extend prongs on the finished button out 90 degrees.
3. Push extended prongs through the front side of the rosette.
4. Bend the prongs flush against the backside of the rosette.
5. Using glue or staples, attach the supplied cardboard backing to the rosette.

That's it! You're done!

Thank you for purchasing our Easy-Step Rosette Kit,
we appreciate your business!

