

# INSTRUCTIONS FOR AQUABELLE FOUNTAIN HEAD (ITEM # 02089) AND OTHER ITEMS USING THE AQUABELLE FOUNTAIN HEAD

## CARE AND INSTALLATION



Pump not included

INSTALL THE FOUNTAIN SO THAT, AT A MINIMUM, THE ENTIRE TOP BODY OF THE FOUNTAIN IS ABOVE WATER LEVEL. ADD THE EXTENSION TUBE AND COUPLING INCLUDED IN THE KIT TO ELEVATE THE FOUNTAIN HEAD ABOVE WATER LEVEL, IF NECESSARY.

THE FOUNTAIN TUBE WILL FIT MOST PUMPS WITH  $\frac{1}{4}$  " MALE PIPE THREADS OR  $\frac{1}{2}$  " OD BARBED NOZZLES. IF THE TUBE IS LOOSE ON THE PUMP OUTLET THREADS WRAP TAPE AROUND THE THREADS UNTIL THE TUBE FITS SNUGLY. THIS FOUNTAIN KIT WORKS WELL WITH PONDMASTER MODEL 1.5 AND 1.9 PUMPS.

BEFORE STARTING PUMP ADJUST DEFLECTOR SO IT IS APPROXIMATELY  $\frac{1}{4}$  ' FROM THE BODY OF THE FOUNTAIN. START THE PUMP AND OBSERVE THE SIZE OF THE BELL SHAPE. TO INCREASE THE DIAMETER, PUSH DOWN WHILE TWISTING ON THE CENTER SECTION.

ADJUST THE WIDTH OF THE AQUABELLE TO YOUR PREFERENCE. IF THE BELL SHAPE STARTS TO BREAK UP AROUND THE OUTER EDGES, IT INDICATES THAT THE PUMP HAS REACHED ITS MAXIMUM OR DEBRIS IS CLOGGING THE FOUNTAIN OR PUMP INTAKE.

## SPECIAL INSTRUCTIONS FOR BARREL KIT (ITEM # 02272), 190 PUMP & FOUNTAIN KIT (ITEM # 02273)

1. POSITION THE KIT IN THE POND ON A FLAT SURFACE. THE WATER FLOW CAN BE ADJUSTED BY TURNING THE WATER FLOW ON THE FRONT OF THE PUMP.
2. FOLLOW THE CARE AND INSTALLATION INSTRUCTIONS. IF THE TUB IS SITUATED IN A WINDY PLACE. ADJUST THE BELL SO THE WATER IS NOT BLOWN OVER THE EDGE AND IS LOST.
3. IF THE WATER FLOW BEGINS TO SLOW, THIS PROBABLY MEANS THE FILTER MEDIA NEEDS TO BE CLEANED. THIS CAN EASILY BE DONE BY REMOVING THE FILTER AROUND THE PUMP AND RINSING IT THOROUGHLY.  
(REPLACEMENT FOAM BLOCK ITEM# 12600)

## INSTRUCTIONS FOR THE 5' X 5' PVC LINER (ITEM #02111), BARREL KIT WITH LINER/PUMP (ITEM #02160)

1. POSITION THE CENTER OF THE LINER OVER THE CENTER OF THE BARREL OR TUB.
2. PUSH THE LINER ALL THE WAY DOWN TO THE BOTTOM AND AGAINST THE SIDES OF THE TUB.
3. PICK A START POINT AND BEGIN TO FOLD THE LINER IN SMALL SECTIONS (4"-6") SMOOTHING OUT THE LINER. USE THUMB TACKS OR HEAVY DUTY STAPLES ( $\frac{1}{2}$ "-1" FROM THE TOP OF THE LINER) TO SECURE THE FOLDS TO THE BARREL.
4. CUT THE EXCESS OF THE LINER ABOVE THE RIM SO THAT THE LINER IS EVEN WITH THE TOP.
5. FILL THE BARREL WITH WATER TO APPROXIMATELY 2" FROM THE RIM.

FOR ADDED ENJOYMENT ADD A DANNER MFG. SUBMERSIBLE LIGHT KIT TO ENJOY YOUR POND IN THE EVENING. IT COMES WITH FOUR COLORED LENSES, 18' POWER CORD, STAND, AND LOW VOLTAGE TRANSFORMER AS ONE UNIT. (ITEM# 02155)

**INSTRUCTIONS FOR AQUABELLE FOUNTAIN HEAD (ITEM # 02089)  
AND OTHER ITEMS USING THE AQUABELLE FOUNTAIN HEAD**

**ELECTRICAL PRECAUTIONS**

Always use a properly grounded outlet. Do not immerse plug in water. DO NOT REACH INTO WATER TO REMOVE PLUG. TURN OFF CIRCUIT FIRST. A "drip loop" should be provided. The "drip loop" is a loop in the cord below the level of the receptacle or plug that prevents water from traveling along the cord. The National Electric Code requires that a ground fault circuit interrupter (GFCI) be installed in the branch circuit supplying fountain or pond equipment. Your dealer can supply GFCI units. NEVER REMOVE GROUND PIN FROM PLUG. **WARNING; FOR YOUR PROTECTION ALWAYS UNPLUG THE UNIT FROM ITS POWER SOURCE BEFORE INSTALLING OR SERVICING. SHOULD THE UNIT APPEAR TO BE NOT WORKING DO NOT REACH, REMOVE OR DISASSEMBLE UNIT BEFORE YOU DISCONNECT POWER.** The pump is intended to pump water only. It cannot be used to pump oils, solvents, or gasoline.

**CAUTION:** PONDS CAN BE DANGEROUS TO SMALL CHILDREN.  
NEVER LEAVE CHILDREN UNSUPERVISED NEAR A POND!

DANNER MFG. INC. 160 OVAL DRIVE, ISLANDIA NEW YORK 11749-1489

VISIT OUR WEB SITE: [WWW.DANNERMFG.COM](http://WWW.DANNERMFG.COM)