

### Getting to know your device

### Insert the SIM card

*The SIM card is not included in the package. A Nano SIM card is available from the user's local operator.*

- Unscrew the back cover and remove.
- Insert the SIM card and make sure it's activated and in credit.
- Replace the cover and tighten the screws.

**!!! Before installing the SIM card, check if the SIM card has a PIN code or not. If yes, please use a mobile phone to remove the card's PIN code.**

### Charge your device

*There are two ways to charge your device.*

**Charging base**

- Place the device on the charging base.
- Connect the USB cable from the charging base to the AC adaptor.

The charging base light will glow when charging and turn solid when fully charged.

**!!! When using the device for the first time, please fully charge the battery for around 2-3 hours.**

**!!! When the battery level falls below 20% it will send a low battery warning message to recipients on the contact list via text message or APP.**

### Switching device on and off

- To turn the device on:** press the CALL button for 1 second, all the LEDs will flash rapidly. The device can also be turned on automatically by charging via magnetic USB cable or put it into the docking station.
- To turn the device off:** press and hold the side button and SOS button together for 3 seconds until the LEDs turn off.

### What do the lights mean?

**Cellular signal indicator-Green**

<b>Green</b>	Light shows a single flash rapidly every 3 seconds	Light shows a double flash rapidly every 3 seconds
<b>Meaning</b>	The device has a stable cellular signal	The device is registered to the cellular network

**Positioning indicator-Blue**

<b>Blue</b>	Light shows a single flash rapidly every 3 seconds	Light shows a double flash rapidly every 3 seconds	Light off
<b>Meaning</b>	The device has no latest location fix	The device has latest location fix	The device is not fixing the latest location

www.safeguardian.com  
800-378-2957

**Power indicator-Red**

<b>Red</b>	Light on (solid)	Light shows a double flash rapidly every 3 seconds
<b>State</b>	Device has been fully charged	BLE connected

<b>Red</b>	Light blinking quickly	Red off or blinking slowly
<b>State</b>	Battery power is lower than 20%	The device is charging

### Activating an SOS alarm

When you need help, press the SOS button for 3-4 seconds until you hear a voice prompt, indicating an SOS alarm. This starts the sequence of sending a "help me!" text message to your emergency contact numbers followed by the outgoing calls.

If the device fails to connect to the first number, it will call the second number after delay of 10 seconds. In case the second number fails to be connected as well, the system will connect to the third number etc.

- Between each call, there will be a 10-second delay, during which time, the user can stop the call sequence or prevent a possible false alarm by pressing the SOS button.
- Use the side buttons +/- to adjust the sound volume during a call.

**!!! Please remember to program emergency contact numbers. It is not mandatory for all ten authorized numbers to be set, however a minimum of one must always be set.**

**!!! Please be patient during the call sequence. There can be short delays as the alarm call phones which maybe out of range or delivered to recipients' voicemail.**

### Getting a GPS fix

- To get an initial location for the GPS features, use outdoors or near a window so the device can get a fix on the satellites. This could take a few minutes depending on your environment.

### Making a phone call

- To make a call, press the CALL button for 3 seconds and you will hear a beep, and then it will dial the defined number.
- To end the call, press the SOS button.

### Silent mode button

- Double-click this button to turn off voice warnings; double-click once more to turn voice warnings on.
- Put device on charging base more than 30 seconds, and they will be paired automatically via Bluetooth.

### Specification:

- Dimension: 62mm\*47mm\*17mm
- Weight: 53g
- Battery: Rechargeable, 3.7V, 950mAh
- Charging voltage: 5V DC
- Waterproof: IP67
- 4 locating technologies: GPS, BLE, WIFI, LBS

### Caution:

**Please comply with the instructions to extend the unit life:**

- Don't use or store the unit in dusty places.
- Avoid storing or using the unit likely to be exposed to extremes of temperature.
- Clean the unit with a piece of dry cloth. Don't clean using chemicals or detergents.
- Don't disassemble or refit the unit.
- Using other batteries will cause unwanted situation.

*Warning: Keep the IMEI and SIM card details to maintain Privacy and security.*

### Quick Start Guide