## **GRASS REINFORCEMENT MESH**

GR11 & GR14

14 14 15 E. C.


Easy to install and maintain **ALL STAKE SUPPLY GR** grass protection meshes work best when applied to areas that are reasonably level, even, well drained and with well-established grass growth.


The plastic mesh is applied directly on top of mown grass, held in place by steel u-pins and the grass encouraged to grow and entangle with the mesh.

To get the best results for GR11 and GR14, all mesh needs to be close-fitting to the grass surface. This is achieved by using the metal pins provided.

The U-pins have been designed to fit flush with or just below the profile of the mesh so they are not a trip hazard and the grass can be safely mowed. See diagram (Indicative Pinning Method) for correct pinning angle







From experience and as a guide we suggest that for a **2m x 20m** roll at least **200 pins** are required and;

for a 1m x 10m roll 50 pins are required, approximately 5 per m<sup>2</sup>

From many trials and working projects it has been found that the pins are best placed at 300-350mm along the edges of the rolls and 600-750mm through the centre.

P: 1300 184 400 • E: sales@turfmate.com.au

www.turfmate.com.au

