


LS1 Genie® adjustable lumbar support.

Optional on all Genie® mesh backs.



1 Lumbar position adjustment - From a seated position, reach behind to the back and grasp the tabs on either side of the lumbar. Squeeze and lift the lumbar support up or down.

Lift up = lumbar up. Lift down = lumbar down.



