

## Online Upgrade

1. Turn on the projector and connect to WiFi.



2. Insert a USB flash drive with at least 50MB storage space to the USB input of the projector. Please note that the format of the USB flash drive must be FAT32.



3. Open the settings, select online update in the advanced interface, click to confirm the upgrade. After completing the update task, the upgrade will be done successfully.

