


DC-ACC-CS1Q Cigarette Lighter Adapter Socket Manual

Features:

The Enforcer cigarette lighter adapter socket is installed directly to the fuse box giving a separate socket for connecting accessories equipped with a standard cigarette lighter power plug. This allows for cleaner installation, frees up the existing cigarette lighter, and is controlled by the ignition switch, thus ensuring accessories don't remain powered and drain the battery when vehicle is off.

Specifications:

Input	12V
Output	12V 2A
Low Voltage Circuit Protection	Yes. Camera will shut down when the voltage is lower than 11.8V
Length	98" (2.5m)
Weight	3 oz. (81g)



Chassis ground

- 1. Connect the red wire of the cigarette lighter adapter socket to the fuse box's ignition switch.
- 2. Connect the black wire of the cigarette lighter adapter socket to chassis ground.
- 3. Plug the car charger into cigarette lighter adapter socket.

Note: To avoid accidentally draining the car's battery, do not connect to fuse connectors that have constant power even when ignition is off.

WARRANTY: This SECO-LARM product is warranted against defects in material and workmanship while used in normal service for 1 (one) year from the date of sale to the original customer.

NOTICE: The information and specifications printed in this manual are current at the time of publication. However, the SECO-LARM policy is one of continual development and improvement. For this reason, SECO-LARM reserves the right to change specifications without notice. SECO-LARM is also not responsible for misprints or typographical errors. Copyright © 2014 SECO-LARM U.S.A., Inc. All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of SECO-LARM.

SECO-LARM® U.S.A., Inc.

16842 Millikan Avenue, Irvine, CA 92606 Phone: (949) 261-2999 | (800) 662-0800 Website: www.seco-larm.com Email: sales@seco-larm.com ■ PITTW5

MiDC-ACC-CS1Q 140818.docx