


SlideDriver™ — Key Release


An overview of the manual key release cable mechanism is shown in the following illustrations and photographs.




SlideDriver interior showing cable release mechanism



Lock assembly MX001526 on chassis.



Eyebolt mounting location (VF series)




1. Use key to unlock release mechanism.
2. To release toggle handle and wheels from the drive rail, pull hard on the cable.

SlideDriver™ — Key Release



SlideDriver interior showing cable release mechanism



SlideDriver 15—Top view interior showing mounting location of eyebolt inside control box.