




ProStereo F3

i.Tech Hi-Res Audio Headphones
www.itechdynamic.com

Quick Start Guide



Performance Tip


To obtain full audio performance from ProStereo F3, allow the earphones to run in continuously for a minimum of 20 hours.

提升音質

讓ProStereo F3連續播唱20小時以上，音質將會獲得全面提升。

提升音质

让ProStereo F3连续播唱20小时以上，音质将会获得全面提升。



EN 1. About your ProStereo F3

- Multi-function Button (MFB)**
 - Answer / End a call
 - Play / Pause
 - Enable Voice Recognition
 - Music Track Control
- Microphone**
- 3.5mm Jack**
- Volume Up Button (+)**
- Volume Down Button (-)**

2. Basic Operation

Function	Button
Music play / pause	Press MFB once
Answer / End an incoming call	Press MFB once
Decline an incoming call	Long press MFB and release
Enable Voice Recognition	Long press MFB when the phone is not in a call
Increase volume	Press Volume Up Button (+) once during music playback or voice call

Function	Button
Decrease volume	Press Volume Down Button (-) once during music playback or voice call
Music track forward	Press MFB twice consecutively during music playback
Music track backward	Press MFB 3 times consecutively during music playback

Note: Some remote features may be limited in certain smartphones.

EN

- Check and observe local laws regarding the use of a mobile phone and a headset while driving. If you use the headset while driving, ensure your full attention and focus. It is your responsibility to drive safely. Consider to pull off the road before making or answering a call.
- Never leave your headset above any air bag deployment area inside your car as serious injury may result when an air bag deploys.
- Never allow children to play with the headset – Small parts may be of choking hazard.
- To prevent damage to your hearing, please do not set the listening volume too high.
- Do not attempt to modify the headset.
- Do not keep the headset near a wash basin or other wet places.
- Do not use the headset outdoors in the rain.
- Do not use the headset in stormy weather.

Care and Maintenance

- Disconnect your headset before placing it in your pocket or bag. If the MFB is accidentally depressed, your mobile phone may place an unintended call.
- Do not expose the headset to liquid, moisture or humidity, or rain as it is not waterproof.
- Do not use abrasive cleaners to clean the headset.
- Do not expose the headset to extremely high or low temperatures.
- Do not leave the headset in direct sunlight for an extended period of time.
- Do not leave the headset near open flames such as cooking burners.
- Do not dispose of the headset in a fire, as it will result in explosion.
- Do not bring the headset into contact with any sharp objects, as this will cause scratches and damages.

- Do not stick anything inside the headset, as this may damage internal components.
- Do not attempt to disassemble the headset as it does not contain serviceable components.
- If you do not plan to use the headset for a long period, please store it in a dry place that is free from extreme temperatures and dust.
- Dispose of the headset according to local regulations. Do not dispose of them as household waste.

EN Notes on Environmental Protection

After the implementation of the European Directive 2012/19/EU in the national legal system, the following applies: Electrical and electronic devices must not be disposed of with domestic waste. Consumers are obliged by law to return electrical and electronic devices at the end of their service lives to the public collection points that are set up for this purpose or designated points of sale. However, such details are defined by the national law of the respective country. This symbol on the product, the instruction manual or the packaging indicates that the product is subject to these regulations. By recycling, reusing the materials, or other forms of utilizing old devices, you are making an important contribution in protecting our environment.

i.Tech Dynamic Global Distribution Limited.
All rights in this publication are reserved and no part may be reproduced without the prior written permission of the publisher. The contents of this publication are believed to be correct at the time of going to press, but any information, specifications, products or services mentioned, and product I.D. shown may be modified, supplemented or withdrawn without further notice. The Stylized i.Tech logos are trademarks owned by i.Tech Dynamic Global Distribution Limited or its affiliates. All other trademarks or registered trademarks belong to their respective owners. i.Tech declares under our sole responsibility that the headset is in conformity with the provisions of the following Council Directives: 2014/53/EU

Version 1.0

All features, functionality and other product specifications, as well as the information contained in this guide, are based upon the latest available information and believed to be accurate at the time of printing. i.Tech reserves the right to change or modify any information or specifications without notice or obligation. The latest version of this guide can be obtained from www.itechdynamic.com. The images in this guide are for reference only.

The Stylized i.Tech logos are registered trademarks.

Dispose of the packaging and this product in accordance with the latest provisions **Printed in China**

Type: HF3AA

繁中 1. 關於您的 ProStereo F3

- 多功能按鍵 (MFB)**
 - 接聽 / 結束來電
 - 播放 / 暫停音樂
 - 啟動語音辨識
 - 歌曲控制
- 麥克風**
- 3.5mm音頻插頭**
- 音量加鍵**
- 音量減鍵**

2. 基本操作

功能	按鍵
播放 / 暫停播放音樂	按 MFB 一次
接聽 / 掛斷來電	按 MFB 一次
拒絕來電	長按 MFB後放開
啟動語音辨識	在未通話時長按 MFB

繁中

功能	按鍵
音量增加	於音樂播放時或通話中按音量加鍵 (+) 一次
音量減少	於音樂播放時或通話中按音量減鍵 (-) 一次
下一首歌曲	於音樂播放時連續按二次 MFB
上一首歌曲	於音樂播放時連續按三次 MFB

注意：部分操控功能或會受個別智能手機型號而有所限制。

安全指引

- 駕駛時請先查閱當地有關使用手提電話及耳機的法例。使用本耳機時，必須保持集中，注意路面情況。為閣下安全著想，請小心駕駛。可考慮先把車輛停泊于路旁，再撥打或接聽電話。
- 切勿把本耳機放在車內安全氣袋的位置上，因為當安全氣袋彈出時，可能會引致嚴重的傷害。
- 切勿讓兒童玩耍本耳機，細小的零件可能令兒童有窒息的危險。
- 為閣下聽覺著想，請勿把音量調得太大。
- 切勿試圖對本耳機作出任何修改。
- 切勿把本耳機放置在洗手盆或其他潮濕的地方。
- 切勿在雨中使用本耳機。
- 切勿在颶風時使用本耳機。

護理及保養

- 將耳機放進口袋或手提袋前，請先把耳機跟手機分開。如果誤按多功能按鍵，您的手機可能會意外撥號。
- 因為耳機是不防水的，切勿讓耳機接觸液體，水分，濕氣或雨水。
- 切勿使用具磨蝕性的清潔劑清理耳機。
- 切勿將耳機暴露在溫度過高或過低的地方。
- 切勿讓耳機長時間受陽光直接照射。
- 切勿讓耳機靠近明火，如煮食爐。
- 切勿棄置耳機於火中，因為這將導致爆炸。
- 切勿讓耳機接觸到任何尖銳的物體，因為這會造成劃痕和損毀。
- 切勿在耳機內戳刺任何物品，因為這可能會損害內部零件。

- 切勿嘗試拆開耳機，因為它並不包含任何維修組件。
- 如果長時期內不打算使用耳機，請你將它儲存在乾燥的地方，避免極端的溫度和灰塵。
- 請根據地方法規棄置耳機。不要將它當作家居廢物般棄置。

有關環保注意事項

自從在國家法律體系中實施歐盟指令2012/19/EU後，以下措施開始應用：電器及電子產品不能作一般家居廢物處理。如在電器產品壽命終結時，消費者將根據法例規定，將產品棄置於特定的公共收集點或銷售點作回收用途，但細節須由相關國家的國家法律所定義。產品、說明書或包裝上的標誌，說明這類產品是受到這些法例的規定，循環使用或再用這些物料或使用其他形式的器材，將對環境保護有著重大貢獻。

繁中

愛達克環球有限公司
所有在本刊物的資料均具有版權，沒有印刷商的書面同意，不得作出任何翻印。在印刷前，所有在本刊物的內容均屬真實正確，但任何資料、規格、產品或提及的服務，以及展視的產品ID,可能會修改、補充或撤銷或未事先通知。時尚的i.Tech標記是愛達克環球有限公司或其附屬公司擁有的商標。所有其他商標或註冊商標屬於相應的擁有者。i.Tech 聲明在其唯一的責任下，本耳機是符合下列委員會指令的條款：2014/53/EU

簡中 1. 关于您的 ProStereo F3

- 多功能按键 (MFB)**
 - 接听 / 结束来电
 - 播放 / 暂停音乐
 - 启动语音辨识
 - 歌曲控制
- 麦克风**
- 3.5mm 音频插头**
- 音量加键**
- 音量减键**

2. 基本操作

功能	按键
播放 / 暂停播放音乐	按 MFB 一次
接听 / 挂断来电	按 MFB 一次
拒绝来电	长按 MFB后放开
启动语音辨识	在未通话时长按 MFB

2. 基本操作

功能	按键
音量增加	於音乐播放时或通話中按音量加键 (+) 一次
音量减少	於音乐播放时或通話中按音量减键 (-) 一次
下一首歌曲	於音乐播放时连续按二次 MFB
上一首歌曲	於音乐播放时连续按三次 MFB

注意：部分操控功能或会受个别智能手机型号而有所限制。

安全指引

- 驾驶时请先查阅当地有关使用手提电话及耳机的法例。使用本耳机时，必须保持集中，注意路面情况。为阁下安全着想，请小心驾驶。可考虑先把车辆停泊于路旁，再拨打或接听电话。
- 切勿把本耳机放在车內安全气囊的位置上，因为当安全气囊弹出时，可能会引致严重的伤害。
- 切勿让儿童玩耍本耳机，细小的零件可能令儿童有窒息的危险。
- 为阁下听觉着想，请勿把音量调得太大。
- 切勿试图对本耳机作出任何修改。
- 切勿把本耳机放置在洗手盆或其他潮濕的地方。
- 切勿在雨中使用本耳机。
- 切勿在台风时使用本耳机。

簡中 护理及保养

- 将耳机放进口袋或手提袋前，请先把耳机跟手机分开。如果误按多功能按键，您的手机可能会意外拨号。
- 因为耳机是不防水的，切勿让耳机接触液体，水分，湿气或雨水。
- 切勿使用具磨蚀性的清洁剂清理耳机。
- 切勿将耳机暴露在温度过高或过低的地方。
- 切勿让耳机长时间受阳光直接照射。
- 切勿让耳机靠近明火，如煮食炉。
- 切勿弃置耳机于火中，因为这将导致爆炸。
- 切勿让耳机接触到任何尖銳的物体，因为这会造成划痕和損毀。
- 切勿在耳机內戳刺任何物品，因为这可能会損害內部零件。

- 切勿尝试拆开耳机，因为它并不包含任何维修组件。
- 如果长时期內不打算使用耳机，请将它储存在乾燥的地方，避免極端的溫度和灰塵。
- 請根據地方法規弃置耳机。不要將它当作家居廢物般弃置。

有关环保注意事项

自从在國家法律體系中實施歐盟指令 2012/19/EU 后，以下措施开始应用：电器及电子产品不能作一般家居废物处理。如在电器产品寿命终结时，消费者将根据法例规定，将产品弃置于特定的公共收集点或销售点作回收用途，但细节须由相关国家的国家法律所定义。产品、说明书或包装上的标志，说明这类产品是受到这些法例的规定，循环使用或再用这些物料或使用其他形式的器材，将对环境保护有着重大贡献。

爱达克环球有限公司
所有在本刊物的数据均具有版权，没有印刷商的书面同意，不得作出任何翻印。在印刷前，所有在本刊物的内容均屬真实正确，但任何数据、规格、产品或提及的服务，以及展视的产品ID,可能会修改、补充或撤銷或未事先通知。时尚的i.Tech标记是爱达克环球有限公司或其附屬公司擁有的商標。所有其他商標或註冊商標屬於相應的擁有者。i.Tech 聲明在其唯一的責任下，本耳机是符合下列委员会指令的条款：2014/53/EU