


Log Set Assembly



Part number list on following page.

IMPORTANT: THIS IS DATED INFORMATION. Parts must be ordered from a dealer or distributor. **Hearth and Home Technologies does not sell directly to consumers.** Provide model number and serial number when requesting service parts from your dealer or distributor.




**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
	Log Set Assembly		7002-009	Y
1	Blower, Convection		812-4900	Y
2	Blower Access Plate, Rear		7008-141	
3	Transition Assembly		7008-011	
4	Top Assembly	Pre SN 0021652643	SRV7008-027	
		Post SN 0021652643	7008-027	
5	Latch Assembly, Stationary		7003-006	Y
6	Brick Retainer		479-0190	
7	Refractory Support, Rear		7002-128	
8	Brick Set		7002-002	
9	Refractory Support, Left		7002-130	
10	Grill Bar Assembly, Rod, BLACK	Pre SN 0021652643	SRV7008-009	
		Post SN 0021652643	7008-009	
	Grill Bar Assembly, Rod	Gold	RDGRL-GD	
		Nickel	RDGRL-NL	
11	Door Assembly with Glass	Pre SN 0021652643	DOOR-COLBAY-INS	
		Post SN 0021652643	DOOR-COLBAY-INB	
12	Door Crown	Pre SN 0021652643	SRV462-0150	
		Post SN 0021652643	462-0150	
13	Door, Face Access	Pre SN 0021652643	SRV7008-117	
		Post SN 0021652643	7008-117	
14	Burner with Neck Assembly		SRV7002-005	Y
15	Refractory Support, Right		7002-129	
	Conversion Kit NG		844-8230	Y
	Conversion Kit LP		LPK-MB	Y
	Pilot Orifice NG		2103-116	Y
	Pilot Orifice LP		200-2630	Y
	Regulator NG		230-1570	Y
	Regulator LP		230-1520	Y

Additional service part numbers appear on following page.

#16 Bottom Firebox Assembly



IMPORTANT: THIS IS DATED INFORMATION. Parts must be ordered from a dealer or distributor. **Hearth and Home Technologies does not sell directly to consumers.** Provide model number and serial number when requesting service parts from your dealer or distributor.



**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
16.1	Pilot Assembly NG(for LP use LP Pilot Orifice)		7003-014	Y
	Pilot Assembly NG (with Injector)		842-4280	Y
16.2	Speed Control		842-0370	Y
16.3	Valve Bracket		7008-112	
16.4	Valve NG		842-0240	Y
	Valve LP		842-0230	Y
16.5	Knob Extension, On/ Off		571-534	Y
16.6	Knob, Extension, HI/LO		571-533	Y
16.7	Piezo Ignitor		291-513	Y
16.8	Bulkhead Stop		474-0090	
16.9	Bulkhead		26457	Y
16.10	Air shutter Assembly		7002-016	Y
16.11	Latch Assembly		7003-005	Y
16.12	Burner Support, Front		7002-132	
16.13	Burner support, Rear		7002-127	
	Flex Assembly 24 in		2098-034	Y
	Orifice, NG .106		19837	Y
	Orifice, LP .063		17236	Y

Additional service part numbers appear on following page.

