## **LENNOX HEARTH PRODUCTS**

**Service Replacement Parts List** 

## MP250 MODEL YEAR: 1992

Door & Door Parts	ITEM NO	DESCRIPTION	
G4000 Door Assembly, Gold (includes handle) 15101 Gasket (Interam), 7/32" x 9/16" x 18" (Cut to size, Requires 3 strips between glass and door) 15101 Gasket (Ixi, 3/4" Door Rope 15099 Gasket, Lytherm, 1/8" x 1 1/2" x 12" (Cut to size, Requires 4 strips between glass and clips) 15090 Gasket, Lytherm, 1/8" x 1 1/2" x 12" (Cut to size, Requires 4 strips between glass and clips) 15090-7 Glass, 9 1/2" x 15 3/4" Arched Ceram Pane (Gasket not included) 15000-7 Glass, 9 1/2" x 15 3/4" Arched Ceram Pane (Gasket not included) 15001-1 Spring, Door Handle Coil 15001-1 Blower, Exhaust (60 CFM) Above "SN 3462 (30 CFM exhaust blower P/N 15001 is no longer available, Order from Grainger 4C760) (D 15001-1 Blower, Exhaust (60 CFM) Above "SN 3462 (30 CFM exhaust blower P/N 15001 is no longer available, Order from Grainger 4C760) (D 15001-1 Blower, Room Air, Left, 15009 (gasket 15163 not included) Note: This blower is used on the Left side on models MP40, MP240, MP240, MP250 & WP50. This blower is used on Right side for model HP40. 15002-1 Blower, Room Air, Right, 15007 (gasket 15163 not included) Note: This blower is used on the Right side on models MP40, MP240, MP250 & WP50. This blower is used on left side for models HP40 & TP40/340/440. This blower is used in the Center on model FP60. 15002-1 Control Board, Upgrade, Controller 2009. Replaces Control Board models 15015 / Oll500, 15016 / Oll500S, 15022 / 1000 and 15023 / Emerson (which has no model designation on the face plate) 15057 Disc, Fan 140-20F (Room Fan-Override, 3 prong) 15011 Disc, High Limit (L200-40F, Manual Reset) 15059 Motor, Auger, M-K w/ Coupler (6 RPM, 80 Amps) 15060 Motor, Cup, M-K w/ Coupler (7.2 RPM, .41 Amps) 15080 Motor, Cup, M-K w/ Coupler (8 RPM, .80 Amps) 15080 Motor, Cup, M-K w/ Coupler (1.2 RPM, .41 Amps) 15080 Gasket Kit, Hopper Lid (order 6 feet) 15029 Wire Harness 15089 Gasket Kit, Hopper Lid (order 6 feet) 15029 Wire Harness 15035 Bearing, Pillow Block (for metering cup and auger) 15041 Coupler, 1/2" (Cup & Auger Shaft)	Door & Door Parts		
Sasket (Interam), 7/32" x 9/16" x 18" (Cut to size, Requires 3 strips between glass and door)	27M67	Clip Set, Glass	
Sasket (Interam), 7/32" x 9/16" x 18" (Cut to size, Requires 3 strips between glass and door)	G4000	Door Assembly, Gold (includes handle)	
Gasket Kit, 34" Door Rope Gasket, Lytherm, 1/8" x 1 1/2" x 12" (Cut to size, Requires 4 strips between glass and clips) G2000-7 Glass, 9 1/2" x 15 3/4" Arched Ceram Pane (Gasket not included) 10300 Handle Assembly, Door S5-11 Spring, Door-Handle Coil Electrical Parts  15001-1 Blower, Exhaust (60 CFM) Above "SN 3462 (30 CFM exhaust blower P/N 15001 is no longer available, Order from Grainger 4C760) (0) H0222 Blower, Room Air, Left, 35009 (gasket 15163 not included) Note: This blower is used on the Left side on models MP40, MP240, MP250 & WP50. This blower is used on Right side for model HP40. H0221 Blower, Room Air, Right, 15007 (gasket 15163 not included) Note: This blower is used on the Right side on models MP40, MP240, MP250 & WP50. This blower is used on left side for models HP40 & TP40/340/440. This blower is used in the Center on model FP60.  28M61 Control Board, Upgrade, Controller 2000 - Replaces Control Board models 15015 / Oll500, 15016 / Oll500S, 15022 / 1000 and 15023 / Emerson (which has no model designation on the face plate)  15057 Disc, Fan 140-20F (Room Fan-Override, 3 prong) 15011 Disc, High Limit (L200-40F, Manual Reset) 15656 Disc, Low Limit (Safety disc, F110-20F) 15070 Motor, Auger, M-K w/ Coupler (6 RPM, 80 Amps) 15080 Motor, Cup, M-K w/ Coupler (1.2 RPM, .41 Amps) 26M22 Power Cord, 8 ft. (20271) 528 Rheostat, Blower Speed Control (Knob, 10050087, Not Included) -02082 16050205 Thermostat, Wall, Honeywell (Thermostat Wire, 16020204, not included) 15029 Wire Harness Hopper Parts 15035 Bearing, Pillow Block (for metering cup and auger) 15031 Blade, Cup (Order 2 if set is needed) Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2)	15101		
Gasses, 9 1/2" x 15 3/4" Arched Ceram Pane (Gasket not included) Handle Assembly, Door  85-11 Spring, Door Handle Coil  Electrical Parts  15001-1 Blower, Exhaust (60 CFM) Above "SN 3462 (30 CFM exhaust blower P/N 15001 is no longer available, Order from Grainger 4C760) (0) H0222 Blower, Room Air, Left, 15009 (gasket 15163 not included) Note: This blower is used on the Left side on models MP40, MP240, MP250 & WP50. This blower is used on Right side for model HP40.  H0221 Blower, Room Air, Right, 15007 (gasket 15163 not included) Note: This blower is used on the Right side on models MP40, MP240, MP250 & WP50. This blower is used on left side for models HP40 & TP40/340/440. This blower is used in the Center on model PF60.  28M61 Control Board, Upgrade, Controller 2000 - Replaces Control Board models 15015 / Oll500, 15016 / Oll500S, 15022 / 1000 and 15023 / Emerson (which has no model designation on the face plate)  15057 Disc, Fan 140-20F (Room Fan-Override, 3 prong) 15011 Disc, High Limit (L200-40F, Manual Reset) 15050 Motor, Auger, M-K w/ Coupler (6 RPM, 80 Amps) 15060 Motor, Auger, M-K w/ Coupler (6 RPM, 80 Amps) 15060 Motor, Auger, M-K w/ Coupler (1.2 RPM, 41 Amps) 26M22 Power Cord, 8 ft. (02071) 528 Rheostat, Blower Speed Control (Knob, 10050087, Not Included) - 02082 16050205 Thermostat, Wall, Honeywell (Thermostat Wire, 16020204, not included) 16050204 Wire, Thermostat, 20' coil - 18 gage 15029 Wire Harness  Hopper Parts 15035 Bearing, Pillow Block (for metering cup and auger) 15031 Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2) 15041 Coupler, 1/2" (Cup & Auger Shaft)	86-128		
Handle Assembly, Door 85-11 Spring, Door Handle Coil Electrical Parts 15001-1 Blower, Exhaust (60 CFM) Above *SN 3462 (30 CFM exhaust blower P/N 15001 is no longer available, Order from Grainger 4C760) (0) H0222 Blower, Room Air, Left, 15009 (gasket 15163 not included) Note: This blower is used on the Left side on models MP40, MP240, MP250 & WP50. This blower is used on Right side for model HP40. H0221 Blower, Room Air, Right, 15007 (gasket 15163 not included) Note: This blower is used on the Right side on models MP40, MP240, MP250 & WP50. This blower is used on left side for models HP40 & TP40/340/440. This blower is used in the Center on model FP60.  28M61 Control Board, Upgrade, Controller 2000 - Replaces Control Board models 15015 / Oll500, 15016 / Oll500S, 15022 / 1000 and 15023 / Emerson (which has no model designation on the face plate)  15057 Disc, Fan 140-20F (Room Fan-Override, 3 prong) 15011 Disc, High Limit (L200-40F, Manual Reset) 11565 Disc, Low Limit (Safety disc, F110-20F) 10050087 Knob, Rheostat (02107) 15070 Motor, Auger, M-K-w/ Coupler (6 RPM, 80 Amps) 15060 Motor, Cup, M-K-w/ Coupler (1.2 RPM, .41 Amps) 26M22 Power Cord, 8 ft. (02071) 528 Rheostat, Blower Speed Control (Knob, 10050087, Not Included) -02082 16050205 Thermostat, Wall, Honeywell (Thermostat Wire, 16020204, not included) 16020204 Wire, Thermostat, 20' coil - 18 gage 15029 Wire Harness 15089 Gasket Kit, Hopper Lid (order 6 feet) 15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange) 1105 Knob, Top Brass (Hopper) 01105 Miscellaneous Parts 15031 Bearing, Pillow Block (for metering cup and auger) 15041 Coupler, 172" (Cup & Auger Shaft)	15099	Gasket, Lytherm, 1/8" x 1 1/2" x 12" (Cut to size, Requires 4 strips between glass and clips)	
Spring, Door Handle Coil	G2000-7	Glass, 9 1/2" x 15 3/4" Arched Ceram Pane (Gasket not included)	
Electrical Parts  15001-1 Blower, Exhaust (60 CFM) Above "SN 3462 (30 CFM exhaust blower P/N 15001 is no longer available, Order from Grainger 4C760) ⊕  H0222 Blower, Room Air, Left, 15009 (gasket 15163 not included) Note: This blower is used on the Left side on models MP40, MP240, MP250 & WP50. This blower is used on RIght side for model HP40.  H0221 Blower, Room Air, Right, 15007 (gasket 15163 not included) Note: This blower is used on the Right side on models MP40, MP240, MP250 & WP50. This blower is used on left side for models HP40 & TP40/340/440. This blower is used in the Center on model FP60.  28M61 Control Board, Upgrade, Controller 2000 - Replaces Control Board models 15015 / Oll500, 15016 / Oll500S, 15022 / 1000 and 15023 / Emerson (which has no model designation on the face plate)  15057 Disc, Fan 140-20F (Room Fan-Override, 3 prong)  15011 Disc, High Limit (L200-40F, Manual Reset)  1565 Disc, Low Limit (Safety disc, F110-20F)  15070 Motor, Auger, M-K w/ Coupler (6 RPM, .80 Amps)  15080 Motor, Cup, M-K w/ Coupler (1.2 RPM, .41 Amps)  26M22 Power Cord, 8 ft. (02071)  528 Rheostat, Blower Speed Control (Knob, 10050087, Not Included) - 92082  16050205 Thermostat, Wall, Honeywell (Thermostat Wire, 16020204, not included)  16020204 Wire, Thermostat, 20' coil - 18 gage  Wire Harness  15089 Gasket Kit, Hopper Lid (order 6 feet)  15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange)  15035 Bearing, Pillow Block (for metering cup and auger)  BRN133 Blade, Cup (Order 2 if set is needed)  Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2)	10300	Handle Assembly, Door	
Blower, Exhaust (60 CFM) Above *SN 3462 (30 CFM exhaust blower P/N 15001 is no longer available, Order from Grainger 4C760) (3)   Blower, Room Air, Left, 15009 (gasket 15163 not included) Note: This blower is used on the Left side on models MP40, MP240, MP250 & WP50. This blower is used on Right side for model HP40.   Blower, Room Air, Right, 15007 (gasket 15163 not included) Note: This blower is used on the Right side on models MP40, MP240, MP250 & WP50. This blower is used on left side for models HP40 & TP40/340/440. This blower is used in the Center on model FP60.   Control Board, Upgrade, Controller 2000 - Replaces Control Board models 15015 / Oll500, 15016 / Oll500S, 15022 / 1000 and 15023 / Emerson (which has no model designation on the face plate)   Society	85-11	Spring, Door Handle Coil	
available, Order from Grainger 4C760) ① H0222 Blower, Room Air, Left, 15009 (gasket 15163 not included) Note: This blower is used on the Left side on models MP40, MP240, MP250 & WP50. This blower is used on RIght side for model HP40. H0221 Blower, Room Air, Right, 15007 (gasket 15163 not included) Note: This blower is used on the Right side on models MP40, MP240, MP250 & WP50. This blower is used on left side for models HP40 & TP40/340/440. This blower is used in the Center on model FP60.  28M61 Control Board, Upgrade, Controller 2000 - Replaces Control Board models 15015 / Oll500, 15016 / Oll500S, 15022 / 1000 and 15023 / Emerson (which has no model designation on the face plate)  15057 Disc, Fan 140-20F (Room Fan-Override, 3 prong) 15011 Disc, High Limit (L200-40F, Manual Reset) 11565 Disc, Low Limit (Safety disc, F110-20F) 10050087 Knob, Rheostat (02107) 15070 Motor, Auger, M-K w/ Coupler (6 RPM, .80 Amps) 15060 Motor, Cup, M-K w/ Coupler (1.2 RPM, .41 Amps) 26M22 Power Cord, 8 ft. (02071) 528 Rheostat, Blower Speed Control (Knob, 10050087, Not Included) - 02082 16050205 Thermostat, 20' coil - 18 gage 16050204 Wire, Thermostat, 20' coil - 18 gage 15029 Wire Harness 15089 Gasket Kit, Hopper Lid (order 6 feet) 15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange) 15035 Bearing, Pillow Block (for metering cup and auger) 15041 Coupler, 1/2" (Cup & Auger Shaft) 15041 Coupler, 1/2" (Cup & Auger Shaft)	Electrical Parts		
Blower, Room Air, Left, 15009 (gasket 15163 not included) Note: This blower is used on the Left side on models MP40, MP240, MP250 & WP50. This blower is used on RIght side for model HP40.  Blower, Room Air, Right, 15007 (gasket 15163 not included) Note: This blower is used on the Right side on models MP40, MP240, MP250 & WP50. This blower is used on left side for models HP40 & TP40/340/440. This blower is used in the Center on model FP60.  Control Board, Upgrade, Controller 2000 - Replaces Control Board models 15015 / Oll500, 15016 / Oll500s, 15022 / 1000 and 15023 / Emerson (which has no model designation on the face plate)  15057 Disc, Fan 140-20F (Room Fan-Override, 3 prong)  15061 Disc, Low Limit (L200-40F, Manual Reset) 11565 Disc, Low Limit (Safety disc, F110-20F) 10050087 Knob, Rheostat (02107) 15070 Motor, Auger, M-K w/ Coupler (6 RPM, .80 Amps) 15060 Motor, Cup, M-K w/ Coupler (1.2 RPM, .41 Amps) 26M22 Power Cord, 8 ft. (02071) 528 Rheostat, Blower Speed Control (Knob, 10050087, Not Included) - 02082 16050205 Thermostat, Wall, Honeywell (Thermostat Wire, 16020204, not included) 16020204 Wire, Thermostat, 20' coil - 18 gage 16020204 Wire, Thermostat, 20' coil - 18 gage 15029 Wire Harness 15089 Gasket Kit, Hopper Lid (order 6 feet) 15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange) 1105 Knob, Top Brass (Hopper) 01105  Miscellaneous Parts 15035 Bearing, Pillow Block (for metering cup and auger) BRN133 Blade, Cup (Order 2 if set is needed) Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2)	15001-1	· · · · · · · · · · · · · · · · · · ·	
side on models MP40, MP240, MP250 & WP50. This blower is used on RIght side for model HP40.  Blower, Room Air, Right, 15007 (gasket 15163 not included) Note: This blower is used on the Right side on models MP40, MP250 & WP50. This blower is used on left side for models HP40 & TP40/340/440. This blower is used in the Center on model FP60.  28M61 Control Board, Upgrade, Controller 2000 - Replaces Control Board models 15015 / OII500, 15016 / OII500S, 15022 / 1000 and 15023 / Emerson (which has no model designation on the face plate)  15057 Disc, Fan 140-20F (Room Fan-Override, 3 prong) 15011 Disc, High Limit (L200-40F, Manual Reset) 11565 Disc, Low Limit (Safety disc, F110-20F) 10050087 Knob, Rheostat (02107) 15070 Motor, Auger, M-K w/ Coupler (6 RPM, .80 Amps) 15060 Motor, Cup, M-K w/ Coupler (1.2 RPM, .41 Amps) 26M22 Power Cord, 8 ft. (02071) 528 Rheostat, Blower Speed Control (Knob, 10050087, Not Included) - 02082 16050205 Thermostat, Wall, Honeywell (Thermostat Wire, 16020204, not included) 16020204 Wire, Thermostat, 20' coil - 18 gage 15029 Wire Harness  Hopper Parts 15089 Gasket Kit, Hopper Lid (order 6 feet) 15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange) 1105 Knob, Top Brass (Hopper) 01105  Miscellaneous Parts 15035 Bearing, Pillow Block (for metering cup and auger)  BRN133 Blade, Cup (Order 2 if set is needed) Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2) 15041 Coupler, 1/2" (Cup & Auger Shaft)	H0222		
side on models MP40, MP240, MP250 & WP50. This blower is used on left side for models HP40 & TP40/340/440. This blower is used in the Center on model FP60.  28M61 Control Board, Upgrade, Controller 2000 - Replaces Control Board models 15015 / Oll500, 15016 / Oll500S, 15022 / 1000 and 15023 / Emerson (which has no model designation on the face plate)  15057 Disc, Fan 140-20F (Room Fan-Override, 3 prong) 15011 Disc, High Limit (L200-40F, Manual Reset) 11565 Disc, Low Limit (Safety disc, F110-20F) 10050087 Knob, Rheostat (02107) 15070 Motor, Auger, M-K w/ Coupler (6 RPM, .80 Amps) 15060 Motor, Cup, M-K w/ Coupler (1.2 RPM, .41 Amps) 26M22 Power Cord, 8 ft. (02071) 528 Rheostat, Blower Speed Control (Knob, 10050087, Not Included) - 02082 16050205 Thermostat, Wall, Honeywell (Thermostat Wire, 16020204, not included) 16020204 Wire, Thermostat, 20' coil - 18 gage 15029 Wire Harness 15089 Gasket Kit, Hopper Lid (order 6 feet) 15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange) 1105 Knob, Top Brass (Hopper) 01105  Miscellaneous Parts 15035 Bearing, Pillow Block (for metering cup and auger) BRN133 Blade, Cup (Order 2 if set is needed) Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2) 15041 Coupler, 1/2" (Cup & Auger Shaft)	110222		
OII500S, 15022 / 1000 and 15023 / Emerson (which has no model designation on the face plate)  15057 Disc, Fan 140-20F (Room Fan-Override, 3 prong) 15011 Disc, High Limit (L200-40F, Manual Reset) 11565 Disc, Low Limit (Safety disc, F110-20F) 10050087 Knob, Rheostat (02107) 15070 Motor, Auger, M-K w/ Coupler (6 RPM, .80 Amps) 15060 Motor, Cup, M-K w/ Coupler (1.2 RPM, .41 Amps) 26M22 Power Cord, 8 ft. (02071) 528 Rheostat, Blower Speed Control (Knob, 10050087, Not Included) - 02082 16050205 Thermostat, Wall, Honeywell (Thermostat Wire, 16020204, not included) 16020204 Wire, Thermostat, 20' coil - 18 gage 15029 Wire Harness  Hopper Parts 15089 Gasket Kit, Hopper Lid (order 6 feet) 15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange) 1105 Knob, Top Brass (Hopper) 01105  Miscellaneous Parts 15035 Bearing, Pillow Block (for metering cup and auger) BRN133 Blade, Cup (Order 2 if set is needed) Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2) 15041 Coupler, 1/2" (Cup & Auger Shaft)	H0221	side on models MP40, MP240, MP250 & WP50. This blower is used on left side for models HP40 &	
15011 Disc, High Limit (L200-40F, Manual Reset) 11565 Disc, Low Limit (Safety disc, F110-20F) 10050087 Knob, Rheostat (02107) 15070 Motor, Auger, M-K w/ Coupler (6 RPM, .80 Amps) 15060 Motor, Cup, M-K w/ Coupler (1.2 RPM, .41 Amps) 26M22 Power Cord, 8 ft. (02071) 528 Rheostat, Blower Speed Control (Knob, 10050087, Not Included) - 02082 16050205 Thermostat, Wall, Honeywell (Thermostat Wire, 16020204, not included) 16020204 Wire, Thermostat, 20' coil - 18 gage 15029 Wire Harness Hopper Parts 15089 Gasket Kit, Hopper Lid (order 6 feet) 15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange) 1105 Knob, Top Brass (Hopper) 01105  Miscellaneous Parts 15035 Bearing, Pillow Block (for metering cup and auger) BRN133 Blade, Cup (Order 2 if set is needed) Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2) 15041 Coupler, 1/2" (Cup & Auger Shaft)	28M61	, ·	
11565 Disc, Low Limit (Safety disc, F110-20F) 10050087 Knob, Rheostat (02107) 15070 Motor, Auger, M-K w/ Coupler (6 RPM, .80 Amps) 15060 Motor, Cup, M-K w/ Coupler (1.2 RPM, .41 Amps) 26M22 Power Cord, 8 ft. (02071) 528 Rheostat, Blower Speed Control (Knob, 10050087, Not Included) - 02082 16050205 Thermostat, Wall, Honeywell (Thermostat Wire, 16020204, not included) 16020204 Wire, Thermostat, 20' coil - 18 gage 15029 Wire Harness  Hopper Parts 15089 Gasket Kit, Hopper Lid (order 6 feet) 15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange) 1105 Knob, Top Brass (Hopper) 01105  Miscellaneous Parts 15035 Bearing, Pillow Block (for metering cup and auger) BRN133 Blade, Cup (Order 2 if set is needed) Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2) 15041 Coupler, 1/2" (Cup & Auger Shaft)	15057	Disc, Fan 140-20F (Room Fan-Override, 3 prong)	
10050087 Knob, Rheostat (02107) 15070 Motor, Auger, M-K w/ Coupler (6 RPM, .80 Amps) 15060 Motor, Cup, M-K w/ Coupler (1.2 RPM, .41 Amps) 26M22 Power Cord, 8 ft. (02071) 528 Rheostat, Blower Speed Control (Knob, 10050087, Not Included) - 02082 16050205 Thermostat, Wall, Honeywell (Thermostat Wire, 16020204, not included) 16020204 Wire, Thermostat, 20' coil - 18 gage 15029 Wire Harness  Hopper Parts 15089 Gasket Kit, Hopper Lid (order 6 feet) 15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange) 1105 Knob, Top Brass (Hopper) 01105  Miscellaneous Parts 15035 Bearing, Pillow Block (for metering cup and auger) BRN133 Blade, Cup (Order 2 if set is needed) Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2) 15041 Coupler, 1/2" (Cup & Auger Shaft)	15011	Disc, High Limit (L200-40F, Manual Reset)	
15070 Motor, Auger, M-K w/ Coupler (6 RPM, .80 Amps) 15060 Motor, Cup, M-K w/ Coupler (1.2 RPM, .41 Amps) 26M22 Power Cord, 8 ft. (02071) 528 Rheostat, Blower Speed Control (Knob, 10050087, Not Included) - 02082 16050205 Thermostat, Wall, Honeywell (Thermostat Wire, 16020204, not included) 16020204 Wire, Thermostat, 20' coil - 18 gage 15029 Wire Harness Hopper Parts 15089 Gasket Kit, Hopper Lid (order 6 feet) 15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange) 1105 Knob, Top Brass (Hopper) 01105  Miscellaneous Parts 15035 Bearing, Pillow Block (for metering cup and auger) BRN133 Blade, Cup (Order 2 if set is needed) Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2) 15041 Coupler, 1/2" (Cup & Auger Shaft)	11565	Disc, Low Limit (Safety disc, F110-20F)	
15060 Motor, Cup, M-K w/ Coupler (1.2 RPM, .41 Amps) 26M22 Power Cord, 8 ft. (02071) 528 Rheostat, Blower Speed Control (Knob, 10050087, Not Included) - 02082 16050205 Thermostat, Wall, Honeywell (Thermostat Wire, 16020204, not included) 16020204 Wire, Thermostat, 20' coil - 18 gage 15029 Wire Harness  Hopper Parts 15089 Gasket Kit, Hopper Lid (order 6 feet) 15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange) 1105 Knob, Top Brass (Hopper) 01105  Miscellaneous Parts 15035 Bearing, Pillow Block (for metering cup and auger) BRN133 Blade, Cup (Order 2 if set is needed) Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2) 15041 Coupler, 1/2" (Cup & Auger Shaft)	10050087	Knob, Rheostat (02107)	
26M22 Power Cord, 8 ft. (02071)  528 Rheostat, Blower Speed Control (Knob, 10050087, Not Included) - 02082  16050205 Thermostat, Wall, Honeywell (Thermostat Wire, 16020204, not included)  16020204 Wire, Thermostat, 20' coil - 18 gage  15029 Wire Harness  Hopper Parts  15089 Gasket Kit, Hopper Lid (order 6 feet)  15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange)  1105 Knob, Top Brass (Hopper) 01105  Miscellaneous Parts  15035 Bearing, Pillow Block (for metering cup and auger)  BRN133 Blade, Cup (Order 2 if set is needed)  Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2)  15041 Coupler, 1/2" (Cup & Auger Shaft)	15070	Motor, Auger, M-K w/ Coupler (6 RPM, .80 Amps)	
Rheostat, Blower Speed Control (Knob, 10050087, Not Included) - 02082  Thermostat, Wall, Honeywell (Thermostat Wire, 16020204, not included)  Wire, Thermostat, 20' coil - 18 gage  Wire Harness  Hopper Parts  Sasket Kit, Hopper Lid (order 6 feet)  Sasket, Burner/Hopper (Between bottom hopper flange and metering cup flange)  Knob, Top Brass (Hopper) 01105  Miscellaneous Parts  Bearing, Pillow Block (for metering cup and auger)  BRN133  Blade, Cup (Order 2 if set is needed)  Not Available  Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2)  Coupler, 1/2" (Cup & Auger Shaft)		Motor, Cup, M-K w/ Coupler (1.2 RPM, .41 Amps)	
Thermostat, Wall, Honeywell (Thermostat Wire, 16020204, not included)  Wire, Thermostat, 20' coil - 18 gage  Wire Harness  Hopper Parts  Saket Kit, Hopper Lid (order 6 feet)  Saket, Burner/Hopper (Between bottom hopper flange and metering cup flange)  Knob, Top Brass (Hopper) 01105  Miscellaneous Parts  Saket Kit, Hopper Lid (order 6 feet)  Saket, Burner/Hopper (Between bottom hopper flange and metering cup flange)  Miscellaneous Parts  Saket Kit, Hopper Lid (order 6 feet)  Saket, Burner/Hopper (Between bottom hopper flange and metering cup flange)  Miscellaneous Parts  Saket Kit, Hopper Lid (order 6 feet)  Saket Kit, Hopper Lid (or	26M22	Power Cord, 8 ft. (02071)	
16020204 Wire, Thermostat, 20' coil - 18 gage 15029 Wire Harness  Hopper Parts 15089 Gasket Kit, Hopper Lid (order 6 feet) 15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange) 1105 Knob, Top Brass (Hopper) 01105  Miscellaneous Parts 15035 Bearing, Pillow Block (for metering cup and auger) BRN133 Blade, Cup (Order 2 if set is needed) Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2) 15041 Coupler, 1/2" (Cup & Auger Shaft)	528		
Hopper Parts  15089 Gasket Kit, Hopper Lid (order 6 feet)  15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange)  1105 Knob, Top Brass (Hopper) 01105  Miscellaneous Parts  15035 Bearing, Pillow Block (for metering cup and auger)  BRN133 Blade, Cup (Order 2 if set is needed)  Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2)  15041 Coupler, 1/2" (Cup & Auger Shaft)			
Hopper Parts  15089 Gasket Kit, Hopper Lid (order 6 feet)  15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange)  1105 Knob, Top Brass (Hopper) 01105  Miscellaneous Parts  15035 Bearing, Pillow Block (for metering cup and auger)  BRN133 Blade, Cup (Order 2 if set is needed)  Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2)  15041 Coupler, 1/2" (Cup & Auger Shaft)			
15089 Gasket Kit, Hopper Lid (order 6 feet)  15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange)  1105 Knob, Top Brass (Hopper) 01105  Miscellaneous Parts  15035 Bearing, Pillow Block (for metering cup and auger)  BRN133 Blade, Cup (Order 2 if set is needed)  Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2)  15041 Coupler, 1/2" (Cup & Auger Shaft)	15029	Wire Harness	
15162 Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange) 1105 Knob, Top Brass (Hopper) 01105  Miscellaneous Parts 15035 Bearing, Pillow Block (for metering cup and auger) BRN133 Blade, Cup (Order 2 if set is needed) Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2) 15041 Coupler, 1/2" (Cup & Auger Shaft)	<b>Hopper Part</b>	S	
Miscellaneous Parts  15035 Bearing, Pillow Block (for metering cup and auger)  BRN133 Blade, Cup (Order 2 if set is needed)  Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2)  15041 Coupler, 1/2" (Cup & Auger Shaft)	15089	Gasket Kit, Hopper Lid (order 6 feet)	
Miscellaneous Parts  15035 Bearing, Pillow Block (for metering cup and auger)  BRN133 Blade, Cup (Order 2 if set is needed)  Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2)  15041 Coupler, 1/2" (Cup & Auger Shaft)	15162	Gasket, Burner/Hopper (Between bottom hopper flange and metering cup flange)	
15035 Bearing, Pillow Block (for metering cup and auger)  BRN133 Blade, Cup (Order 2 if set is needed)  Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2)  15041 Coupler, 1/2" (Cup & Auger Shaft)	1105	Knob, Top Brass (Hopper) 01105	
BRN133 Blade, Cup (Order 2 if set is needed)  Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2)  15041 Coupler, 1/2" (Cup & Auger Shaft)	Miscellaneous Parts		
Not Available Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2) 15041 Coupler, 1/2" (Cup & Auger Shaft)	15035	Bearing, Pillow Block (for metering cup and auger)	
15041 Coupler, 1/2" (Cup & Auger Shaft)	BRN133	Blade, Cup (Order 2 if set is needed)	
15041 Coupler, 1/2" (Cup & Auger Shaft)	Not Available	Blades, Wiper/Multi-Fueled Units Only (1990 Models) Replaced by BRN133 (order 2)	
15039 Coupler, 3/8" (Cup & Auger Motor Shaft) Durham Motors Only	15041		
	15039	Coupler, 3/8" (Cup & Auger Motor Shaft) Durham Motors Only	

15501	Gasket, Flue Outlet
15031	Gear, Aluminum Spyder
H0534	Marble Set, Gray, MS1502 (marble gasket, 1ea. 1054 & 4ea. 1051, is provided w/appliance)
H0535	Marble Set, Green, MS1505 (marble gasket, 1ea. 1054 & 4ea. 1051, is provided w/appliance)
70K99	Paint, Black Metallic, 12 oz. Spray #6309 (76-141MB)
15050-5	Plug, 1/8" (Spacer for metering cup when burning corn)
15050-6	Plug, 3/8" (Spacer for metering cup when burning corn)
BRN120	Propeller, Cup/Auger Motor (Black - Durham Motors Only)
15078	Propeller, Cup/Auger Motor (White - Merkle Korpf Motors Only)
Firepot & F	Firebox Parts
15169C	Corn Pot Assembly (Includes 1/8" & 3/8" plugs)
16238	Cover, Clean Out (38108 Gasket not included)
15149	Firepot, Pellet
38108	Gasket, Clean-Out cover
PL300	Log Set, Refractory (units w/ Firepots mfg'd before 3/95)
PL500	Log Set, Split (units w/ Fireports mfg'd after 3/95)
15411	Plate, Baffle

<sup>\*</sup> SN - Stove serial number range, parts are compatible with:

">" = greater than # indicated, "<" = less than # indicated, "-" = numbers within range.

① To use Grainger blower, air shutter from original blower will need to be transferred to new blower.