

Part number list on following page.

IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.




**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
	Log Assembly		4035-156	Y
1	Top Casting	Ref: Black	464-0140MBK	
2	Heater Assembly		4035-155	Y
3	Air Channel	Qty. 2 req.	4035-321	
4	Air Deflector		4035-305	
5	Flame Panel		4035-308	
6	Lens		4035-804	Y
7	Back Glass		4035-801	Y
8	Side Casting - Qty. 2 req.	Ref: Black	7016-109MBK	
9	Upper Casting Support	Qty. 2 req.	4035-306	
10	Lower Casting Support	Qty. 2 req.	4035-307	
11	Ember Bed		4035-818	Y
12	Hearth Pan		4035-205	
13	Front Screen Assembly		4035-151	Y
14	Front Casting	Ref: Black	464-0160MBK	
15	Retainer	Qty. 2 req.	4035-311	
16	Flame Element Kit		4035-153	Y
17	Parabolic Reflector		4035-309	
18	Split Bushing	Qty. 2 req.	4021-177	
19	Halogen Bulb		33961	Y
20	Socket Assembly		4035-152	Y
21	Outer Bottom Light Shield		4035-322	Y
22	Box Bottom		4035-302	
23	Bottom Light Shield		4035-320	
24	Light Shield		4035-318	
25	Box Front		4035-300	
26	Motor		4035-860	
27	Front Reflector		4035-316	
28	Snap-in Cord Clip		25611	
29	Bi-metal Thermostat		4035-808	Y
30	Box Back		4035-301	
31	Rocker Switch	Qty. 2 req.	060-511	Y
32	Knob (Thermostat)		4035-826	Y
33	Two Prong Power Cord		4030-802	Y
34	Strain Relief Bushing		4030-873	
35	Knob		19942	Y
36	Variable Control		4035-809	Y

**** Contact your local distributor/dealer to order Casting parts.**

Service Parts Diagram
Linden Green Electric Appliance

Beginning Manufacturing Date: Oct. 2004
Ending Manufacturing Date: Oct. 2005



Part number list on following page.


IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
	Log Assembly		4035-156	Y
1	Top Casting	Ref: Linden Green	464-0140	
2	Heater Assembly		4035-155	Y
3	Air Channel	Qty. 2 req.	4035-321	
4	Air Deflector		4035-305	
5	Flame Panel		4035-308	
6	Lens		4035-804	Y
7	Back Glass		4035-801	Y
8	Side Casting - Qty. 2 req.	Ref: Linden Green	7016-109PWD	
9	Upper Casting Support	Qty. 2 req.	4035-306	
10	Lower Casting Support	Qty. 2 req.	4035-307	
11	Ember Bed		4035-818	Y
12	Hearth Pan		4035-205	
13	Front Screen Assembly		4035-151	Y
14	Front Casting	Ref: Linden Green	464-0160	
15	Retainer	Qty. 2 req.	4035-311	
16	Flame Element Kit		4035-153	Y
17	Parabolic Reflector		4035-309	
18	Split Bushing	Qty. 2 req.	4021-177	
19	Halogen Bulb		33961	Y
20	Socket Assembly		4035-152	Y
21	Outer Bottom Light Shield		4035-322	Y
22	Box Bottom		4035-302	
23	Bottom Light Shield		4035-320	
24	Light Shield		4035-318	
25	Box Front		4035-300	
26	Motor		4035-810	
27	Front Reflector		4035-316	
28	Snap-in Cord Clip		25611	
29	Bi-metal Thermostat		4035-808	Y
30	Box Back		4035-301	
31	Rocker Switch	Qty. 2 req.	060-511	Y
32	Knob (Thermostat)		4035-826	Y
33	Two Prong Power Cord		4030-802	Y
34	Strain Relief Bushing		4030-873	
35	Knob		19942	Y
36	Variable Control		4035-809	Y

**** Contact your local distributor/dealer to order Casting parts.**



Part number list on following page.


IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
	Log Assembly		4035-156	Y
1	Top Casting	Ref: Merlot	464-0140	
2	Heater Assembly		4035-155	Y
3	Air Channel	Qty. 2 req.	4035-321	
4	Air Deflector		4035-305	
5	Flame Panel		4035-308	
6	Lens		4035-804	Y
7	Back Glass		4035-801	Y
8	Side Casting - Qty. 2 req.	Ref: Merlot	7016-109PWD	
9	Upper Casting Support	Qty. 2 req.	4035-306	
10	Lower Casting Support	Qty. 2 req.	4035-307	
11	Ember Bed		4035-818	Y
12	Hearth Pan		4035-205	
13	Front Screen Assembly		4035-151	Y
14	Front Casting	Ref: Merlot	464-0160	
15	Retainer	Qty. 2 req.	4035-311	
16	Flame Element Kit		4035-153	Y
17	Parabolic Reflector		4035-309	
18	Split Bushing	Qty. 2 req.	4021-177	
19	Halogen Bulb		33961	Y
20	Socket Assembly		4035-152	Y
21	Outer Bottom Light Shield		4035-322	Y
22	Box Bottom		4035-302	
23	Bottom Light Shield		4035-320	
24	Light Shield		4035-318	
25	Box Front		4035-300	
26	Motor		4035-810	
27	Front Reflector		4035-316	
28	Snap-in Cord Clip		25611	
29	Bi-metal Thermostat		4035-808	Y
30	Box Back		4035-301	
31	Rocker Switch	Qty. 2 req.	060-511	Y
32	Knob (Thermostat)		4035-826	Y
33	Two Prong Power Cord		4030-802	Y
34	Strain Relief Bushing		4030-873	
35	Knob		19942	Y
36	Variable Control		4035-809	Y

**** Contact your local distributor/dealer to order Casting parts.**



Part number list on following page.

IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



Stocked
at Depot

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
	Log Assembly		4035-156	Y
1	Top Casting	Ref: Mahogany	464-0140	
2	Heater Assembly		4035-155	Y
3	Air Channel	Qty. 2 req.	4035-321	
4	Air Deflector		4035-305	
5	Flame Panel		4035-308	
6	Lens		4035-804	Y
7	Back Glass		4035-801	Y
8	Side Casting - Qty. 2 req.	Ref: Mahogany	7016-109POR	
9	Upper Casting Support	Qty. 2 req.	4035-306	
10	Lower Casting Support	Qty. 2 req.	4035-307	
11	Ember Bed		4035-818	Y
12	Hearth Pan		4035-205	
13	Front Screen Assembly		4035-151	Y
14	Front Casting	Ref: Mahogany	464-0160	
15	Retainer	Qty. 2 req.	4035-311	
16	Flame Element Kit		4035-153	Y
17	Parabolic Reflector		4035-309	
18	Split Bushing	Qty. 2 req.	4021-177	
19	Halogen Bulb		33961	Y
20	Socket Assembly		4035-152	Y
21	Outer Bottom Light Shield		4035-322	Y
22	Box Bottom		4035-302	
23	Bottom Light Shield		4035-320	
24	Light Shield		4035-318	
25	Box Front		4035-300	
26	Motor		4035-810	
27	Front Reflector		4035-316	
28	Snap-in Cord Clip		25611	
29	Bi-metal Thermostat		4035-808	Y
30	Box Back		4035-301	
31	Rocker Switch	Qty. 2 req.	060-511	Y
32	Knob (Thermostat)		4035-826	Y
33	Two Prong Power Cord		4030-802	Y
34	Strain Relief Bushing		4030-873	
35	Knob		19942	Y
36	Variable Control		4035-809	Y

** Contact your local distributor/dealer to order Casting parts.