

IMPORTANT NOTICE

This manual is intended primarily for use by professional bicycle mechanics. Users who are not professionally trained for bicycle assembly should not attempt to install the components

If any part of the information on the manual is unclear to you, do not proceed with the installation. Instead, contact your dealer or a local bicycle shop for their assistance.

Make sure to read all instruction manuals included with the product.

You can find all the manuals and specs on our website http://ingrid.bike

MAINTENANCE

This product is not guaranteed against natural wear and deterioration from normal use and aging.

!!! PERIODICALLY CHECK THE TIGHTENING. INCORRECT TIGHTENING CAN CAUSE MALFUNCTIONS OR BREAKAGE

MOSCONI s.r.l. | via la Villa 28 zona artigianale Ghilardino 61034 Fossombrone, PU


BOTTOM BRACKET SPECIFICATION


OUR CRANKSET SYSTEM IS DESIGNED WITH AN ASIMMETRY OF +2.5MM ON DRIVE SIDE

The common MTB frames/BB cups are asymmetrical and that provides the necessary configuration (fig.1)


The common ROAD frames/BB cups are symmetrical. In this case add 2.5 mm on the drive side (fig.2)


VERIFY THAT THE FRAME/BB CUPS COMPLIES WITH THE REQUIRED DIMENSIONS FOR OUR SPINDLES

















CRANCKSET DISASSEMBLY

SELF-EXTRACTOR RING and SCREW REPLACE

