
Assembly Instructions

Oxford TV Unit 520589



1-8

2021-08-28



Keep these instructions for future reference

Assemble the furniture on a soft level surface to avoid damaging the furniture or your floor.

We recommend furniture be assembled near where they will be placed, to avoid moving the product unnecessarily once assembled.


If there is a need to move the furniture, please remove all loose items and have extra hands to help lift the furniture to the desired location. Dragging the furniture will damage both the furniture and the floor.

Regularly check and re-tighten (if necessary) all bolts on furniture that you have assembled yourself.

NOTE:


It is essential that this product is fixed to a wall using the strap supplied. Wall fixings are not supplied, different walls require unique wall fixings. For advice on suitable wall fixings, contact your local specialised dealer.

2-8 2021-08-28




Ax8	Bx10	Cx2	Dx2
M6x10mm	M6x30mm	M6x480mm	M6x15mm
Ex12	Fx12	Gx1	Hx1
M6x15mm		4mm	5mm
lx2			

3-8 2021-08-28




2











4







5-8


2021-08-28





6
























8-8 2021-08-28