
# **ASSEMBLY INSTRUCTIONS**Console Table



#### **Care instructions**

- Only clean the item using a damp cloth and mild detergent. Do not use abrasive cleaners.
- Use a dry cloth to clean the product, furniture polish is not recommended.
- From time to time check that there are no loose screws, nuts or bolts. if there are please re-tighten.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

#### **Assembly instructions**

- Never use power tools unless specially instructed. They can damage your components or hardware if used incorrectly.
- The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- Never use any glue until you are certain that the parts belong together.





WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY.

To avoid any serious or fatal injury, this product has been fitted with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

#### What you need

to assemble the product 1 x Philips head screwdriver (NOT PROVIDED)





## Step 1


You will need

8 x Bolt (H1)

8 x Flat washer (H2)

1 x Allen key (H3)


Note: Assemble the console table on a soft flat surface to prevent unit from being damaged during assembly.



Fix the legs frame (P3) to legs frame (P2).

Using 8 bolts (H1) & 8 washers (H2). Tighten the bolts with Allen key (H3).


#### Step 2




(P1) with n key (H3).

Loosely attach the frame legs to table top (P1) with 8 bolts (H1) and 8 washers (H2) with Allen key (H3).


### Step 3







Align the frame legs to table top (P1) as shown. Tighten the bolts with Allen key (H3).


#### Step 4






Fix wall strap (H5) to the underside of the table top (P1) with 1 screw (H4) and 1 washer (H6) by tightening with the Phillips head screwdriver.





strap to the wall securely

# Step 7



#### **Job Complete!**