


ASSEMBLY INSTRUCTION


G5347KD - ENTERTAINMENT UNIT_KD

No.	Part name	Q'ty
-----	-----------	------


(A)	Top frame	1
-----	-----------	---




(B)	Legs	2
-----	------	---







(C)	Legs	2
-----	------	---




(D)	Shelf frame	1
-----	-------------	---




No.	Hardware name	Q'ty
(1)	Bolt M6x60 	12
(2)	Spring Washers 	12
(3)	Flat Washers 	12
(4)	Allen key K4 	1

Take out the drawers




STEP 1

STEP 2



STEP 2

Insert the drawers



STEP 3

FINAL

