








# ASSEMBLY INSTRUCTION

## G6775- TV UNIT

No	PARTS NAME	Q.ty (pcs)
A	 TV Unit	1



No	LIST OF HARDWARE	Q.ty (pcs)
①	Bolts M6x60 	9
②	Allen key K4 	1
③	Handles 	3
④	Flat screw Ø3.5 x 12 	6
Screwdriver (not included) 