









ASSEMBLY INSTRUCTION

G7352 - SMALL TV UNIT 1100

No	PARTS NAME	Q.ty (pcs)
Ⓐ	 TV Unit	1



Ⓑ	 Legs Frame	1 Set
---	---	-------

No	LIST OF HARDWARE	Q.ty (pcs)
①	Bolts M6x55 	9
②	Allen key K4 	1
③	Handles 	2
④	Flat screw Ø3.5 x 12 	4
Screwdriver (not included) 