










ASSEMBLY INSTRUCTION

G7438 - TV UNIT

No	PARTS NAME	Q.ty (pcs)
Ⓐ	 Cabinet	1
Ⓑ	 Legs	4
Ⓒ	 Center Leg	1

STEP 1



No	LIST OF HARDWARE	Q.ty (pcs)
①	Bolts M6x50 	8
②	Spring Washers M6 	9
③	Flat Washers M6 	9
④	Allen key K4 	1
⑤	Bolts M6x35 	1

STEP 2

