

BRiNK

Dry Herb Vaporizer



FLEX
TEMP



SUB-OHM



NANO GLAZED
CHAMBER




WARRANTY
PROGRAM



0.5G
0.5 GRAM
CAPACITY



4:20
SESH TIME



1800
mAh

NEW
C-CORE
TECHNOLOGY

The Brink is the very first sub-ohm flower vaporizer! That means you can expect full-bodied vapor production at every temperature level thanks to the low resistance airflow.

HOW TO USE THE BRINK

1. Remove the magnetic cap and load up to 0.5g of ground dry herbs. Replace the mouthpiece.
2. Click the power button 5x to turn the device on. It will buzz once and start heating to your last-used temperature.
3. Use the +/- buttons to adjust the temperature level and then hold the power button for 2 seconds. There are 3 temperature ranges:



320°F-340°F



350°F-370°F



372°F-400°F

4. To adjust the temperature range after the heat cycle has started, press and hold the button for 2 seconds. Press and hold again to resume the cycle. Each session will run for 4 minutes and 20 seconds.
5. Press the power button 5x to turn the Brink off or set it and forget it. It will automatically shut off after 10 minutes of inactivity.

INDICATORS:

-  Temperature Indicator Light
-  Battery Indicator Light

The battery lights will tell you if your device is turning on or off!



POWER UP

POWER DOWN

THE BRINK'S BATTERY

- 1800 mAh – 10-12 sessions per charge.
- Press the button 4x to check your battery level. It will flash for 3 seconds:




100%-61%



60%-31%



30%-1%



- Includes a universal type-c charging cable with type-c protocol. This means it works well with European adapters, too.
- Always use a wall outlet to charge the Brink. We prefer the adapter boxes that come with smartphones, but any standard usb adapters will do.

HOW TO CLEAN THE BRINK

1. Empty out any leftover debris in the chamber and remove the filter screen (if you are using one).
 - This pill-shaped screen is designed to be used with super finely-ground herbs. If yours has broken down into more of a fine dust than a chunky grind, we recommend using a screen.
2. Use a brush or Ooze Resolution Micro Swab to remove any stubborn residue.
 - DO NOT FLOOD THE CHAMBER WITH RUBBING ALCOHOL.
3. Remove the screen from under the mouthpiece and clean with a brush or wipe. If needed, replace with a new screen.
4. Let all the pieces dry completely and reassemble.

ACTIVATE YOUR WARRANTY!

Registration info on the back



REGISTER YOUR BRINK

- 1.** Your Brink has an authentication code etched onto the back of the device, near the bottom.
- 2.** Go to ooze.life/register and use this code to fill out the registration form.
- 3.** Submit the form. Your Brink is officially registered in our system, and your warranty is activated!

SAFE GUARDS

-  Keep away from water.
-  Only charge indoors.
-  Only charge with included charger - no others!
-  Only use in legal and adult use state/province/country.
-  Only use approved Ooze attachments.
-  Never leave unattended around children/pets.
-  Never disassemble.
-  Only use wall outlet for charging.
-  Do not leave unattended while charging.
-  Do not leave charging overnight.
-  Always dry thoroughly after cleaning.



@OOZELIFE #OOZELIFE
[WWW.OOZELIFE.COM](https://www.ooze.life)