

QUAD

FLEX TEMP BATTERY

INSTRUCTION MANUAL



**510
THREAD**



**DUAL CHARGING
PORTS**



**PREP
MODE**



**AUTO
SHUT OFF**



**FLEX TEMP
BATTERY**



QUAD FLEX TEMP BATTERY



POWER BUTTON

To turn on, press the power button 5x fast.

The Quad will automatically shut off after 12 minutes.



FLEX TEMP

Press the button 3x fast to select your preferred temperature level.

2.7V

3.2V


3.7V

4.2V



PREHEAT MODE


To start press the power button twice. Indicator light will gradually change color. To end press power button once.



USB SMART CHARGER

Indication light
● FULLY CHARGED
● CHARGING

HOW TO CHARGE



Type-C:

Plug a Type-C charging cord into the port located on the bottom of the device.



USB Smart Charger:

Screw the 510 charger into the universal port. Plug the charger in using a wall adapter.

Important Safeguards:

Device is to be used with the included charger for **indoor** use only.

WARRANTY INFORMATION

Enter the 6 digit authentication code printed on your battery or card in the box, at oozelifelife.com/apps/product-registration to register your product.