


# GreX 2638

16 Gauge 1-1/2" Length 1" Crown Stapler

# EXPLODED DIAGRAM



# Grex 2638

## 16 Gauge 1-1/2" Length 1" Crown Stapler

# PARTS LIST

Part No.	Description
15001	Seal
15003	Spring
15010	Trigger Valve Head
15011	Trigger Valve
15012	Spring
15013	Trigger Valve Guide
15018	Spring
15021	Cap Gasket
15022	Bottom Gasket
15023	Inlet Cap Gasket
15400	Deflector
15410	Cap
15440	Trigger Valve Stem
15453	Primary Trigger
15470	Secondary Trigger
15490	Gun Body
15510	End Cap
15600	Safety Guide
15660	C-Ring
15773	Standard Trigger Assembly
15870	Seal
15880	Seal
22012	Roller
25015	Shaft
25016	Roller Spring
27620	Adjust Wheel
31290	Body Guard
35011	Nose
35020	Nose Cover A
35030	Nose Cover B
35040	Bottom Cap
35060	Magazine
35070	Pusher
35090	Safety B
35120	Plate
35130	Latch Bracket
35140	Shingle Guide
35181	Piston O-Ring
35192	Cylinder
35200	Cylinder Spacer
35210	Bumper
35230	Button
35240	Spring

Part No.	Description
35270	Plate A
35280	Plate B
35290	Guide
35300	Plate C
35321	Piston Ram Assembly
35350	Nose Cover Latch
35371	Safety A Assembly
35430	Safety Spring Sleeve
35460	Sleeve
35500	Head Valve Assembly
88001	Hex. Soc. Head Screw
88006	Hex. Soc. Head Screw
90001	Hex. Soc. Head Set Screw
92001	Lock Nut
92002	Lock Nut
93004	Spring Pin
93008	Spring Pin
93017	Spring Pin
93018	Spring Pin
94001	Coupling Plug
95001	E-Ring
95002	E-Ring
96005	O-Ring
96010	O-Ring
96011	O-Ring
96012	O-Ring
96013	O-Ring
96014	O-Ring
96015	O-Ring
96018	O-Ring
96019	O-Ring
96020	O-Ring
96028	O-Ring
96036	O-Ring
96051	O-Ring
97002	Spring Washer
97003	Spring Washer
99003	Hex. Soc. Head Screw
99005	Hex. Soc. Head Screw
99014	Hex. Soc. Head Screw
99015	Hex. Soc. Head Screw
99017	Hex. Soc. Head Screw
99039	Hex. Soc. Head Screw
99047	Hex. Soc. Head Screw

