


Grex 50AD-LNS, 71AD-LNS, 80AD-LNS

AD-LNS Series Long Nose Fine Wire Staplers

EXPLODED DIAGRAM



Grex 50AD-LNS, 71AD-LNS, 80AD-LNS

PARTS LIST

AD-LNS Series Long Nose Fine Wire Staplers

No.	Part No.	Description
01	23550	Head Cap Hammer
02	96133	O-Ring (Head Cap / Cylinder)
03	96101	O-Ring (Driver Piston)
04	23549	Piston Ram Assembly (50AD-LNS)
	23554	Piston Ram Assembly (71AD-LNS)
	23552	Piston Ram Assembly (80AD-LNS)
05	96100	O-Ring (Head Cap / Cylinder)
06	23553	Cylinder
07	23504	Bumper
8A	23563	Trigger Valve A Assembly
12	23506	Trigger Valve Spring
13	96104	O-Ring C (Trigger Valve)
14	23508	Trigger Valve B (AD Series)
15	96105	O-Ring D (Trigger Valve) AD Series
16	96106	O-Ring E (Trigger Valve) AD Series
17	96107	O-Ring F (Trigger Valve)
18	23509	Trigger Valve Stem (AD Series)
19	23510	Trigger Valve Guide (AD Series)
20	96106	O-Ring E (Trigger Valve)
21	99039	Hex. Soc. Head Screw
22	97002	Spring Washer
23	99026	Hex. Soc. Head Screw
24	23548	Nose (50AD-LNS)
	23555	Nose (71AD-LNS)
	23551	Nose (80AD-LNS)
25	23513	Nose Plate (For all 71, 80)
	23564	Nose Plate (For all 50, A11 & 2116)

No.	Part No.	Description
26	23514	Magazine Cover (50AD, AF & LNS)
	23517	Magazine Cover (71AD, AF & LNS)
	23522	Magazine Cover (80AD, AF & LNS)
27	23049	Pusher Spring
28	23516	Magazine (50AD, AF & LNS)
	23521	Magazine (71AD, AF & LNS)
	23526	Magazine (80AD, AF & LNS)
29	23074	Pusher (50AD, AF & LNS)
	23047	Pusher (71AD, AF & LNS)
	23060	Pusher (80AD, AF & LNS)
30	23518	Rear Magazine Bumper
31	91010	Hex. Soc. Flat Head Screw
32	91004	Hex. Soc. Flat Head Screw
33	23523	Magazine Retainer
34	23519	Pin (Trigger)
35	23524	Trigger
36	23525	Seal
37	23562	Gun Body (AD-LNS Series)
38	23528	Magazine Latch Spring
39	23529	Magazine Latch
40	94001	Coupling Plug
41	23530	Pin (Magazine Latch)
42	95001	E-Ring
43	23531	Air Silencer
44	96110	O-Ring
45	23561	Nose Cover