


# Grex 50AF-LM, 71AF-LM, 80AF-LM

AF Series Auto-Firing Fine Wire Staplers w/ Long Magazine

# EXPLODED DIAGRAM



# Grex 50AF-LM, 71AF-LM, 80AF-LM

# PARTS LIST

## AF-LM Series Auto-Firing Fine Wire Staplers w/ Long Magazine

No.	Part No.	Description
01	23501	Head Cap Hammer
02	96100	O-Ring (Head Cap / Cylinder)
03	96101	O-Ring (Driver Piston)
04	23502	Piston Ram Assembly (50AD, AF & AF-LM)
	23507	Piston Ram Assembly (71AD, AF & AF-LM)
	23512	Piston Ram Assembly (80AD, AF & AF-LM)
05	96100	O-Ring (Head Cap / Cylinder)
06	23532	Cylinder (AF & AF-LM Series)
07	23504	Bumper
8A	23563	Trigger Valve A Assembly
12	23506	Trigger Valve Spring
13	96104	O-Ring C (Trigger Valve)
14	23533	Trigger Valve B (AF & AF-LM Series)
15	96108	O-Ring D (Trigger Valve) AF & AF-LM Series
16	96109	O-Ring E (Trigger Valve) AF & AF-LM Series
17	96107	O-Ring F (Trigger Valve)
18	23534	Trigger Valve Stem (AF & AF-LM Series)
19	23535	Trigger Valve Guide (AF & AF-LM Series)
20	96106	O-Ring E (Trigger Valve)
21	99039	Hex. Soc. Head Screw
22	97002	Spring Washer
23	99026	Hex. Soc. Head Screw
24	23511	Nose (50AD, AF & AF-LM)
	23515	Nose (71AD, AF & AF-LM)
	23520	Nose (80AD, AF & AF-LM)
25	23513	Nose Plate (For All 71 & 80)
	23564	Nose Plate (For all 50, A11 & 2116)
26	23539	Magazine Cover (50AF-LM)
	23540	Magazine Cover (71AF-LM)
	23541	Magazine Cover (80AF-LM)
27	23542	Pusher Spring (AF-LM Series only)
28	23543	Magazine (50AF-LM)
	23544	Magazine (71AF-LM)
	23545	Magazine (80AF-LM)

No.	Part No.	Description
29	23074	Pusher (50AD, AF & AF-LM)
	23047	Pusher (71AD, AF & AF-LM)
	23060	Pusher (80AD, AF & AF-LM)
30	23518	Rear Magazine Bumper
31	91010	Hex. Soc. Flat Head Screw
32	91004	Hex. Soc. Flat Head Screw
33	23523	Magazine Retainer
34	23519	Pin (Trigger)
35	23524	Trigger
36	23525	Seal
37	23537	Gun Body (AF & AF-LM Series)
38	23528	Magazine Latch Spring
39	23546	Magazine Latch (AF-LM Series only)
40	94001	Coupling Plug
41	23530	Pin (Magazine Latch)
42	95001	E-Ring
43	23531	Air Silencer
44	96113	O-Ring 2 Cylinder (AF, AF-LM)
45	23536	Trigger Valve Plate (AF, AF-LM Series)
46	96105	O-Ring Trigger (AF, AF-LM Series)
47	96116	O-Ring Trigger (AF, AF-LM Series)
48	96116	O-Ring Trigger (AF, AF-LM Series)
49	23538	Auto Adjust Knob (AF, AF-LM Series)
50	96114	O-Ring (AF, AF-LM Series)
51	96111	O-Ring (AF, AF-LM Series)
52	96111	O-Ring (AF, AF-LM Series)
53	96115	O-Ring (AF, AF-LM Series)
54	96110	O-Ring
55	23547	Latch Bracket (AF-LM Series only)
56	23561	Nose Cover