



JPS38R

16GA 1" Wide Crown Stapler

NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY
1	BOLT (M6x15L)	Z-06-150	1	28	ROLL PIN (Φ3x22L)	R-30-220	1	56	PUSHER SPRING	JNS45-M-005	1				
2	EXHAUST COVER WASHER	CT64-C-007	1	29	BODY	JPS38R-B-001	1	57	ALL BUSHING	9032-B-009	1				
3	EXHAUST COVER	JN45R-C-003	1	30	GRIP	JN2190-B-004	1	58	MAGAZINE NUT	JPS38R-M-012	1				
4	BOLT (M5x30L)	Z-05-300	4	31	END CAP O-RING	JNS45-B-003	1	59	BOLT (M5x14L)	Z-05-140	4				
5	SPRING WASHER (for M5)	W-05	12	32	END CAP	JNS45-B-002	1	60	SHINGLE GAUGE	JPS38R-M-009	1				
6	GUARD PLATE	JPS38R-C-004	2	33	PLUG CAP	9032-B-006	1	61	SHINGLE GAUGE NUT	JPS38R-M-010	1				
7	NON-SLIP PAD	JN45R-C-005	2	34	AIR PLUG	9032-B-005	1	62	MAGAZINE BODY	JPS38R-M-001	1				
8	CAP	JPS38R-C-001	1	35	BOLT (M5x35L)	ZN-05-350	2	63	PUSHER STOPPER	JPS38R-M-007	1				
9	GASKET	JPS38R-C-002	1	36	GUIDE COVER A	JPS38R-G-002	1	64	PUSHER STOPPER SPRING	951-M-011	1				
10	CAP WASHER	1651-C-003	1	37	BOLT (M5x20L)	ZN-05-200	1	65	STOPPER SEAL	951-M-008	1				
11	PISTON STOPPER	1651-H-005	1	38	DRIVER GUIDE	JPS38R-G-001	1	66	STAPLE RAILING COVER	JPS38R-M-011	1				
12	HEAD VALVE SPRING	1651-H-006	1	39	STAPLE GUIDE	JPS38R-G-108	1	67	MAGAZINE SPRING	JNS45-M-008	1				
13	HEAD VALVE O-RING (IN)	1651-H-003	1	40	BOLT (M5x10L)	ZN-05-100	1	68	BOLT (M5x16L)	Z-05-160	2				
14	HEAD VALVE	1651-H-001	1	41	GUIDE COVER LATCH SET	JPS38R-G-P001	1	69	BRACKET	JPS38R-M-006	1				
15	HEAD VALVE O-RING (OUT)	1651-H-004	1	42	GUIDE COVER B	JPS38R-G-003	1	70	VALVE SET	NV-V-P001	1				
16	HEAD VALVE SEAL	1651-H-002	1	43	GATE PIN	1651S-M-010	1	71	PIN (Φ3x14.2L)	NV-V-013	2				
17	COLLAR	1651-A-004	1	44	STAPLE GUIDE PIN	9032-M-012	1	72	VALVE O-RING	NV-V-001	1				
18	PISTON O-RING	1651-P-003	1	45	PIN STOPPER O-RING	JPS38R-M-008	2	73	PLUNGER CAP O-RING	CT64-V-011	1				
19	PISTON ASSEMBLY	JPS38R-P-P002	1	46	LOCK NUT (for M5)	NN-05	4	74	VALVE	NV-V-003	1				
19A	PISTON SET	JPS38R-P-P001	1	47	ROLL PIN (Φ2.5x16L)	R-25-160	1	75	VALVE PLUNGER O-RING (UP)	NV-V-004	1				
20	CYLINDER	JPS38R-A-001	1	48	TRIGGER A (OUT)	JN45R-T-001	1	76	VALVE PLUNGER	NV-V-007	1				
21	CYLINDER O-RING	1665-A-005	1	49	TRIGGER B (IN)	JN45R-T-002	1	77	VALVE PLUNGER O-RING (MID)	CT64-V-005	1				
22	CYLINDER GUIDE	JPS38R-A-002	1	50	CONTACT HOUSING	JPS38R-S-003	1	78	VALVE PLUNGER O-RING (LOW)	NV-V-006	1				
23	CYLINDER GUIDE O-RING	JPS38R-A-006	1	51	CONTACT SPRING	JNS45-S-004	1	79	PLUNGER O-RING	CT64-V-008	2				
24	SUPPLY HOLE SEAL	1651-A-007	1	52	CONTACT ARM ASSEMBLY	JPS38R-S-P001	1	80	PLUNGER SPRING	CT64-V-009	1				
25	BUMPER	JPS38R-A-003	1	53	MAGAZINE COVER	JPS38R-M-002	1	81	PLUNGER	NV-V-010	1				
26	DRIVER GUIDE PLATE	JPS38R-A-008	1	54	PUSHER	JPS38R-M-003	1	82	PLUNGER CAP	NV-V-012	1				
27	ROLL PIN (Φ3x28L)	R-30-280	2	55	PUSHER CAP	JPS38R-M-008	1								

** All the parts of stapler can be changed for improvement and re-design without announcement.

(REV. : 2012/1/27)

New products and latest information

www.jitool.com

www.crownparts.com

JPS38R

16GA 1" Wide Crown Stapler

