




MODEL : LNF-50AC



- 35A BUMP FIRE SWITCH
- 34A SINGLE FIRE SWITCH
- 33A SINGLE/BUMP FIRE SWITCH

*B : APPLY LOCTITE 242

L13900 07/19/06

PARTS LIST (LNF-50AC)

*WHEN ORDERING SPARE PARTS, PLEASE STATE ITEM No, PART NO. AND DESCRIPTION.

ITEM	PART NO	DESCRIPTION	QTY	ITEM	PART NO	DESCRIPTION	QTY	ITEM	PART NO	DESCRIPTION	QTY
01	HS05080BW-20	HEX. SOC. HD. BOLT+SW	4	49	SS04070B-12	SET SCREW	1				
03	13900306	CAP	1	50	13105001	MAGAZINE	1				
04	12100401	SEAL**	1	51	HS04070BW-08	HEX. SOC. HD. BOLT+SW	4				
05	12100501	SPRING**	1	52	13105201	TAIL COVER	1				
06	OR13824N	O RING**	1	53	13105301	PUSHER	1				
07	11100701	CAP SEAL**	1	54	12105401	SPRING**	1				
08A	13900801A	HEAD VALVE ASM.	1	55	12105501	NAIL GUIDE LINER	1				
11	OR31824N	O RING**	1	57	HS05080B-07	HEX. SOC. HD. BOLT	1				
13-1	OR23735N	O RING**	1	61A	13206101A	BRACKET ASSEMBLY	1				
13-2	13901304	PISTON RING	1	64	HS05080B-16	HEX. SOC. HD. BOLT	1				
14A-1	13901401A	DRIVER ASSEMBLY**	1	65	LN0500N	LOCK NUT	1				
14A-2	13901402A	DRIVER ASSEMBLY**	1	66	11106601	COVER	1				
18	OR44431N	O RING**	1	67	12106401	AIR PLUG	1				
19-1	13901902	CYLINDER	1	68	OR40030N	O RING**	1				
19-2	13901902G	CYLINDER	1	71	US05080B-06	UM. HD. BOLT	1				
19-3	13901903	COLLAR	1	72	FW05012B-08	FLAT WASHER	1				
20	13902001	BUMPER**	1	73	12103301	SEAL	1				
21	OR35020N	O RING**	2	74	13907403	EXHAUST COVER	1				
23	11102309	BODY	1								
24	OR01919N	O RING**	2								
25	10902501	JOINT GUIDE	1								
26	11002601	SPRING	1								
27	11002702	GUIDE SAFETY LEVER	1								
31	13203101	SAFETY LEVER	1								
32	11103201	STEPPED PIN	2								
41	HS05080BW-25	HEX. SOC. HD. BOLT+SW	2								
41A	13104101A	LATCH**	1								
43	RP3020S	ROLLED PIN	1								
44	13104401	DRIVER GUIDE COVER	1								
44A	13104401A	DRIVER GUIDE COVER ASM	1								
45	12104501	SET PLATE	1								
46	HS04070B-12	HEX. SOC. HD. BOLT	2								
47	13104701	DRIVER GUIDE	1								
48	13104801	MAGAZINE COVER	1								