


MODEL MS7564

SPOTNAILS[®]

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd
Rolling Meadows, IL 60008
Phone : 847-259-1620



7/25/2005

SPOTNAILS MODEL MS7564

Ref No.	Part No.	Description	Ref No.	Part No.	Description
01	P-24370	Screw	38	P-07262	Pin
02	P-96118	Bushing	39	P-64332	Valve Housing O-Ring
03	P-70047	Exhaust Deflector	40	P-22144	Trigger Valve Cap
04	P-64377	O-Ring	41	P-64333	O-Ring
05	P-24314	Cap Screw	42	P-64334	O-Ring
06	P-32169	Flat Washer	43	P-64335	O-Ring
07	P-60181	Cap	44	P-22145	Pilot Valve
◆ 08	P-62080	Gasket	45	P-64336	O-Ring
09	P-03076	Spacer	46	P-18227	Spring
10	P-15204	Exhaust Seal	47	P-64383	Plunger O-Rings
11	P-18442	Poppet Spring	48	AS-22037	Plunger Assembly
◆ 12	P-64399	Poppet O-Ring	50	P-64328	O-Ring
13	P-63043	Poppet	51	AS-21008	Trigger Assembly
◆ 14	P-64426	Poppet O-Ring	52	P-07327	Trigger Pin
◆ 15	P-64312	Cylinder Seal O-Ring	53	P-64240	O-Ring
◆ 16	P-64427	Piston O-Ring	54	P-13082	Bracket
17	AS-06060	Piston & Driver Assembly	55	P-24370	Screw
18	P-06241	Driver Blade	56	P-24353	Screw
19	P-03082	Guide Spacer	57	P-12436	Magazine Cover (A)
◆ 20	P-64228	Cylinder O-Ring	58	P-18131	Spring Clip
21	P-05108	Cylinder	59	P-18298	Negator Spring
◆ 22	P-64429	O-Ring	60	P-12444	Magazine
23	P-15215	Bumper	61	P-24383	Screw
24	P-15218	Return Seal	62	P-32180	E-Ring
25	P-01272	Body	63	P-07346	Cover Pin
26	P-64312	O-Ring	64	P-18228	Spring
27	P-60156	End Cap	65	P-32170	Washer
28	P-64430	O-Ring	66	P-26142	Nut
29	P-60182	Bottom Plate	67	P-12437	Magazine Cover (B)
30	P-24453	Screw	68	P-03083	Bushing
31	P-10308	Stationary Front Plate	69	P-09183	Pusher
32	P-24358	Screw	70	P-97454	Filter (Optional)
33	P-08483	Wear Plate	71	AS-04038	Latch Assembly
34	P-07257	Safety Yoke Pin	72	P-07354	Pin
35	P-53165	Safety Guide	73	P-07355	Pin
36	P-18328	Spring	74	P-10309	Removable Front Plate
37	AS-53062	Safety Assembly			

◆ Parts Included In AS-97300 O-Ring And Seal Kit