


MODEL TB1840

SPOTNAILS[®]

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd
Rolling Meadows, IL 60008
Phone : 847-259-1620



5/17/2005

SPOTNAILS MODEL TB1840

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description		
1	P-24370	Screw	32	P-53165	Safety Guide		
2	P-96118	Bushing	33	P-18328	Spring		
3	P-70046	Exhaust Deflector	34	AS-53057	Safety Assembly		
4	P-64377	O-Ring	35	P-64239	O-Ring		
5	P-32217	Washer	36	P-22114	Bleeder Valve		
6	P-24358	Cap Screw	37	P-64241	O-Ring		
7	P-32211	Flat Washer	38	P-18227	Spring		
8	P-60180	Cap	39	P-22179	Plunger		
◆	9	P-15193	Exhaust Seal	◆	40	P-64240	O-Ring
◆	10	P-64384	O-Ring	41	AS-21014	Trigger Assembly	
◆	11	P-18331	Poppet Spring	42	P-07327	Trigger Pin	
◆	12	P-64232	Poppet O-Ring	43	P-24307	Screw	
◆	13	P-63042	Poppet	44	P-32170	Washer	
◆	14	P-64422	Piston Stop O-Ring	45	P-13042	Bracket	
◆	15	P-64234	Cylinder O-Ring	46	P-24313	Screw	
◆	16	P-03081	Guide Spacer	47	P-26126	Nut	
◆	17	P-62079	Gasket	48	P-07329	Retainer Pin	
◆	18	P-05106	Cylinder	49	AS-12164	Magazine Assembly	
◆	19	P-64235	Cylinder O-Ring	50	P-12438	Feeder Cover	
◆	20	P-64423	O-Ring	51	P-12439	Magazine Cover	
◆	21	P-64424	Piston O-Ring	52	P-24301	Screw	
◆	22	P-06239	Driver Blade	53	P-18234	Negator Spring	
◆	23	AS-06057	Piston & Driver Assembly	54	AS-09039	Pusher Assembly	
◆	24	P-15121	Bumper	55	P-07356	Pin	
◆	25	P-15122	Return Seal	56	P-07353	Pin	
◆	26	P-01271	Body	57	AS-04036	Latch Assembly	
◆	27	P-64425	O-Ring	58	P-64434	O-Ring	
◆	28	P-60175	End Cap	59	AS-53061	No Mar Tip Assembly	
◆	29	P-24300	Screw	60	P-96129	No Mar Tip	
◆	30	AS-10052	Front Plate Assembly	61	P-32227	Washer	
◆	31	P-07262	Pin	62	P-26165	Nut	

◆ Parts Included in AS-97301 O-Ring and Seal Kit