



TRS25B (16GA. 1" WIDE CROWN STAPLER)

NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY
1	BOLT (M6x20L)	Z-06-200	1	25	CYLINDER GUIDE O-RING	JPS38R-A-006	1	50	ROLL PIN (Φ2.5x16L)	R-25-160	1
2	EXHAUST COVER BUSHING	JN2190-C-007	1	26	SUPPLY HOLE SEAL	1651-A-007	1	51	TRIGGER A (OUT)	JN45R-T-001	1
3	EXHAUST COVER A	TRS25S-C-003	1	27	BUMPER	JPS38R-A-003	1	52	TRIGGER B (IN)	JN45R-T-002	1
4	EXHAUST COVER B	951-C-010	1	28	DRIVER GUIDE PLATE	TRS25B-A-008	1	53	LOCK NUT (for M5)	NN-05	2
5	EXHAUST COVER SEAL	951-C-009	1	29	ROLL PIN (Φ3x30L)	R-30-300	1	54	PUSHER PIN	TRS25S-M-010	1
6	BOLT (M5x30L)	Z-05-300	4	30	BODY	TRS25S-B-001	1	55	PUSHER	TRS25B-M-003	1
7	SPRING WASHER (For M5)	W-05	9	31	GRIP	JN2190-B-004	1	56	PUSHER SPRING	TRS25S-M-005	1
8	GUARD PLATE	JPS38R-C-004	2	32	END CAP O-RING	JNS45-B-003	1	57	ROLLER	TRS25S-M-009	1
9	NON-SLIP PAD	JN45R-C-005	2	33	END CAP	JNS45-B-002	1	58	STOPPER SEAL	951-M-008	2
10	CAP	TRS25S-C-001	1	34	PLUG CAP	9032-B-006	1	59	MAGAZINE	TRS25B-M-001	1
11	GASKET	JPS38R-C-002	1	35	AIR PLUG	9032-B-005	1	60	STAPLE GUIDE	TRS25S-M-011	1
12	CAP WASHER	1651-C-003	1	36	BOLT (M5x35L)	ZN-05-350	2	61	BOLT (M5x10L)	ZN-05-100	1
13	PISTON STOPPER	1651-H-005	1	37	GUIDE COVER A	JPS38R-G-002	1	62	BOLT (M5x14L)	Z-05-140	6
14	HEAD VALVE SPRING	1651-H-006	1	38	DRIVER GUIDE	TRS25B-G-001	1	63	MAGAZINE END CAP	TRS25B-L-001	1
15	HEAD VALVE O-RING (IN)	1651-H-003	1	39	BOLT (M5x20L)	ZN-05-200	2	64	STOPPER SPRING	JNS45-M-009	1
16	HEAD VALVE	1651-H-001	1	40	PIN STOPPER O-RING	JPS38R-M-004	1	65	PUSHER STOPPER	TRS25S-M-007	1
17	HEAD VALVE O-RING (OUT)	1651-H-004	1	41	GUIDE COVER LATCH SET	TRS25S-G-P001	1	66	VALVE SET	TRS25S-V-P001	1
18	HEAD VALVE SEAL	1651-H-002	1	42	GUIDE COVER B	TRS25S-G-003	1	67	VALVE PLUNGER O-RING	CT64-V-004	1
19	COLLAR	1651-A-004	1	43	ROLL PIN (Φ3x40L)	R-30-400	1	68	VALVE PLUNGER	1850-V-007	1
20	PISTON O-RING	1651-P-003	1	44	COVER PIN	9032-M-012	1	69	PLUNGER SPRING	TRS25S-V-009	1
21	PISTON ASSEMBLY	TRS25B-P-P002	1	45	CONTACT ARM	TRS25S-S-101	1	70	PLUNGER O-RING	CT64-V-008	2
21A	PISTON SET	TRS25B-P-P001	1	46	CONTACT SPRING	TRS25S-S-004	1	71	PLUNGER	TRS25S-V-010	1
22	CYLINDER	TRS25S-A-001	1	47	CONTACT HOUSING	JPS38R-S-003	1	72	PLUNGER CAP O-RING	1013-V-011	1
23	CYLINDER O-RING	1665-A-005	1	48	BOLT (M5x16L)	Z-05-160	2	73	PLUNGER CAP	TRS25S-V-012	1
24	CYLINDER GUIDE	JPS38R-A-002	1	49	BRACKET	TRS25S-M-006	1				

** All the parts of stapler can be changed for improvement and re-design without announcement.

(REV. : 2015/01/08)

